



Order	Job/Part	Q'ty	Remarks
5	AC magneto cover gasket	1	
6	Dowel pin	2	
7	Lead holder	1	
8	Crankshaft position sensor	1	
9	Stator coil	1	
10	Torque limiter	1	
11	Starter idle gear	1	
12	Starter idle gear shaft	1	
13	AC magneto rotor	1	Refer to "REMOVING THE AC MAGNETO ROTOR" and "INSTALLING THE AC MAGNETO ROTOR".
14	Starter clutch	1	
15	Woodruff key	1	
16	Starter wheel gear	1	



Order	Job/Part	Q'ty	Remarks
17	Washer	1	For installation, reverse the removal procedure.



EBS00259


REMOVING THE AC MAGNETO ROTOR

1. Remove:

- lead holder ①
- AC magneto cover

NOTE: _____

Loosen each bolt 1/4 of a turn at a time, in stages and in a crisscross pattern. After all of the bolts are fully loosened, remove them.



2. Remove:


- AC magneto rotor nut ①
- washer

NOTE: _____

- While holding the AC magneto rotor ② with the sheave holder ③, loosen the AC magneto rotor nut.
- Do not allow the sheave holder to touch the projection on the rotor.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A



3. Remove:

- AC magneto rotor ①
(with the starter clutch)
- woodruff key

CAUTION: _____


To protect the end of the crankshaft, place an appropriate sized socket between the flywheel puller set center bolt and the crankshaft.

NOTE: _____

- Use the flywheel puller ②.
- Install the flywheel puller bolts to the threaded holes of the starter clutch.
- Make sure the flywheel puller is centered over the AC magneto rotor.



2. Check:
 - starter idle gear teeth
 - starter wheel gear teeth
 Burrs/clips/roughness/wear → Replace.
3. Check:
 - starter wheel gear (contacting surface)
 Damage/pitting/wear → Replace.




CHECKING THE TORQUE LIMITER

- torque limiter
- Damage/wear → Replace.

NOTE:

Do not disassemble the torque limiter.



EBS00268

INSTALLING THE AC MAGNETO ROTOR

1. Install:

- stator coil ①




7 Nm (0.7 m · kg, 5.1 ft · lb)



Stator coil bolt
7 Nm (0.7 m · kg, 5.1 ft · lb)

NOTE:

Align the projection (a) on the stator coil with the slot (b) in the AC magneto cover.



2. Apply:
 - Sealant ① (into the slit)




Yamaha bond No. 1215
90890-85505
(Three bond No.1215®)



3. Install:
- woodruff key
 - AC magneto rotor


NOTE:

- Before installing the rotor, clean the outside of the crankshaft and the inside of the rotor.
- After installing the rotor, check that the rotor rotates smoothly. If not, reinstall the key and rotor.



4. Tighten:

- AC magneto rotor nut ①


 70 Nm (7.0 m · kg, 50 ft · lb)

NOTE:


While holding the AC magneto rotor ② with the sheave holder ③, tighten the AC magneto rotor nut.



Sheave holder
90890-01701
Primary clutch holder
YS-01880-A



5. Install:
- AC magneto cover
 - lead holder ①
 - AC magneto cover bolts


 10 Nm (1.0 m · kg, 7.2 ft · lb)

NOTE:


Tighten the AC magneto cover bolts in stages, using a crisscross pattern.



BALANCER GEARS AND OIL PUMP GEARS



Order	Job/Part	Q'ty	Remarks
	Removing the balancer gears and oil pump gears		Remove the parts in the order listed.
1	Starter wheel gear		Refer to "AC MAGNETO".
2	Lock washer	1	Refer to "REMOVING THE BALANCER DRIVEN GEAR AND OIL PUMP DRIVEN GEAR" and "INSTALLING THE BALANCER DRIVE GEAR, BALANCER DRIVEN GEAR, AND OIL PUMP DRIVEN GEAR".
	Balancer driven gear	1	
3	Oil pump drive gear	1	
4	Chain	1	
5	Straight key	1	



REMOVING THE BALANCER DRIVEN GEAR AND OIL PUMP DRIVEN GEAR

1. Straighten the lock washer tabs.
2. Loosen:
 - balancer driven gear nut ①
 - oil pump driven gear nut ②

NOTE:


Place an aluminum plate ③ between the teeth of the balancer drive gear ④ and balancer driven gear ⑤, then loosen the nuts.

CHECKING THE OIL PUMP DRIVE

1. Check:
 - oil pump drive gear
 - oil pump driven gearCracks/wear/damage → Replace.

CHECKING THE BALANCER DRIVE


1. Check:
 - balancer drive gear
 - balancer driven gearDamage/wear → Replace the balancer drive gear and balancer driven gear as a set.
Excessive noise during operation → Replace the balancer drive gear and balancer driven gear as a set.



INSTALLING THE BALANCER DRIVE GEAR, BALANCER DRIVEN GEAR, AND OIL PUMP DRIVEN GEAR


1. Install:
 - pin
 - spring
 - balancer drive gear (onto the buffer boss)

NOTE: _____
Align the punch mark (a) on the balancer drive gear with the hole (b) to the buffer boss.



2. Install:
 - balancer drive gear ①
 - balancer driven gear ②
 - oil pump driven gear ③

NOTE: _____
• Align the punch mark (a) on the balancer drive gear with the punch mark (b) on the balancer driven gear.
• Install the oil pump driven gear with the “3B4” mark (c) facing out.



3. Install:
 - lock washers **New**
 - oil pump driven gear nut ①

	22 Nm (2.2 m · kg, 16 ft · lb)
--	---------------------------------------
 - balancer driven gear nut ②

	80 Nm (8.0 m · kg, 58 ft · lb)
--	---------------------------------------


NOTE: _____
• Place an aluminum plate (3) between the teeth of the balancer drive gear (4) and balancer driven gear (5), then tighten the nuts.
• Apply the engine oil to the thread of axles and nuts.

4. Bend the lock washer tabs along the balancer driven gear nut and oil pump driven gear nut.




EBS00269

PRIMARY AND SECONDARY SHEAVES



Order	Job/Part	Q'ty	Remarks
	Removing the primary and secondary sheaves		Remove the parts in the order listed.
	Front fender/rear fender		Refer to "ENGINE SKID PLATES, SEAT, CARRIERS AND FENDERS" in chapter 3.
	Right footrest board		Refer to "FOOTREST BOARDS" in chapter 3.
	Air ducts		Refer to "ENGINE REMOVAL".
1	Drive belt cover	1	Refer to "REMOVING THE PRIMARY AND SECONDARY SHEAVES" and "INSTALLING THE PRIMARY AND SECONDARY SHEAVES".
2	Rubber gasket	1	
3	Bearing housing	1	
4	Dowel pin	2	
5	Primary sheave assembly	1	
6	V-belt	1	
7	Primary fixed sheave	1	
8	Secondary sheave assembly	1	




Order	Job/Part	Q'ty	Remarks
9	Drive belt case	1	For installation, reverse the removal procedure.
10	Rubber gasket	1	
11	Rubber gasket	1	



EBS00270

PRIMARY SHEAVE




Order	Job/Part	Q'ty	Remarks
	Disassembling the primary sheave		Remove the parts in the order listed.
①	Primary pulley sheave cap	1	Refer to "ASSEMBLING THE PRIMARY SHEAVE".
②	Primary pulley slider	4	
③	Primary pulley cam	1	
④	Primary pulley weight	8	
⑤	Collar	1	
⑥	Oil seal	2	
⑦	Primary sliding sheave	1	
⑧	O-ring	1	
			For assembly, reverse the disassembly procedure.




EBS00271

SECONDARY SHEAVE



Order	Job/Part	Q'ty	Remarks
	Disassembling the secondary sheave		Remove the parts in the order listed.
①	Nut	1	Refer to "DISASSEMBLING THE SECONDARY SHEAVE" and "ASSEMBLING THE SECONDARY SHEAVE". For assembly, reverse the disassembly procedure.
②	Spring seat	1	
③	Compression spring	1	
④	Spring seat	1	
⑤	Guide pin	4	
⑥	Secondary sliding sheave	1	
⑦	O-ring	2	
⑧	Secondary fixed sheave	1	
⑨	Oil seal	2	




EBS00274

CHECKING THE PRIMARY SHEAVE

1. Check:
 - weight outside diameter ①
Out of specification → Replace the weight.



Weight outside diameter
30 mm (1.18 in)
<Limit>: 29.5 mm (1.16 in)




2. Check:
 - primary pulley slider
 - primary sliding sheave splines
Wear/cracks/damage → Replace.
 - primary pulley cam
Cracks/damage → Replace.
3. Check:
 - primary sliding sheave
 - primary fixed sheave
Cracks/damage → Replace.


EBS00275

CHECKING THE SECONDARY SHEAVE

1. Check:
 - secondary fixed sheave smooth operation
 - secondary sliding sheave smooth operation
Scratches/damage → Replace as a set.




2. Check:
 - torque cam grooves ①
Wear/damage → Replace.
3. Check:
 - guide pins ②
Wear/damage → Replace.
4. Check:
 - secondary sheave spring
Damage → Replace.



5. Measure:

- secondary sheave spring free length ②
- Out of specification → Replace the secondary sheave spring.

	Free length
	130.6 mm (5.14 in)
	<Limit>: 128.0 mm (5.04 in)



EBS00276


ASSEMBLING THE PRIMARY SHEAVE

1. Clean:

- primary sliding sheave face ①
- primary fixed sheave face ②
- collar ③
- weights ④
- primary sliding sheave cam face

NOTE: _____

Remove any excess grease.




2. Install:


- weights ①


NOTE: _____

- Apply Yamaha Grizzly grease (90 g) to the whole outer surface of the weights and install.
- Apply Yamaha Grizzly grease (2.5 g) to the inner surface of the collar.
- Apply Yamaha Grizzly grease (2.5 g) to the inner surface of the primary sliding sheave.



3. Install:
- slider ①
 - cam ②
 - primary sliding sheave cap


 3 Nm (0.3 m · kg, 2.2 ft · lb)




EBS00277

ASSEMBLING THE SECONDARY SHEAVE




1. Apply:
- BEL-RAY assembly lube®
(to the secondary sliding sheave ① inner surface and oil seals)
 - BEL-RAY assembly lube®
(to the bearings, oil seals and inner surface of the secondary fixed sheave ②)



2. Install:
- guide pins ①



3. Apply:
- BEL-RAY assembly lube®
(to the guide pin sliding grooves ①, and oil seals ② **New**)



EBS00279

INSTALLING THE PRIMARY AND SECONDARY SHEAVES

1. Install:
 - secondary sheave
 - V-belt
 - primary sheave

NOTE:

- Tightening the bolts ① will push the secondary sliding sheave away, causing the gap between the secondary fixed and sliding sheaves to widen.
- Install the V-belt so that its arrow faces the direction shown in the illustration.

2. Tighten:

- primary sheave nut ①

140 Nm (14.0 m · kg, 100 ft · lb)

- secondary sheave nut ②

100 Nm (10.0 m · kg, 72 ft · lb)

NOTE:

- Use the sheave holder ③ to hold the primary sheave.
- First, tighten the primary sheave nut ①, then tighten the secondary sheave nut ②.




**Sheave holder
90890-01701
Primary clutch holder
YS-01880-A**



EBS00291


CLUTCH




Order	Job/Part	Q'ty	Remarks
	Removing the clutch		
	Primary sheave/secondary sheave		Remove the parts in the order listed. Refer to "PRIMARY AND SECONDARY SHEAVES".
1	Clutch housing assembly	1	Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH".
2	Gasket	1	
3	Dowel pin	2	
4	One-way clutch bearing	1	
5	Nut	1	
6	Clutch carrier assembly	1	
			For installation, reverse the removal procedure.



EBS00292



Order	Job/Part	Q'ty	Remarks
	Disassembling the clutch housing assembly		Remove the parts in the order listed.
①	Oil seal	1	
②	Circlip	1	
③	Bearing housing	1	
④	Circlip	1	
⑤	Bearing	1	
⑥	Circlip	1	
⑦	Bearing	1	
⑧	Clutch housing	1	
			For assembly, reverse the disassembly procedure.




EBS00296

REMOVING THE CLUTCH

1. Remove:
 - clutch housing assembly
 - gasket
 - dowel pins

NOTE:

Working in crisscross pattern, loosen each bolt 1/4 of a turn. Remove them after all of them are loosened.



2. Straighten:
 - punched portion of the nut ①
3. Remove:
 - nut ①

CAUTION:


The clutch carrier assembly nut has left-handed threads. To loosen the clutch carrier assembly nut turn it clockwise.

NOTE:

Use a clutch holding tool ② to hold the clutch carrier assembly.




Universal clutch holder
90890-04086, YM-91042



EBS00309

INSTALLING THE CLUTCH

1. Install:
 - clutch carrier assembly
 - nut ① **New**

 **190 Nm (19.0 m · kg, 140 ft · lb)**

CAUTION:

The clutch carrier assembly nut has left-handed threads. To tighten the clutch carrier assembly nut turn it counterclockwise.


NOTE:

Use a clutch holding tool ② to hold the clutch carrier assembly.



**Universal clutch holder
90890-04086, YM-91042**


2. Lock the threads with a drift punch.




3. Install:
 - one-way clutch bearing

NOTE:

The one-way clutch bearing should be installed in the clutch carrier assembly with the "OUT SIDE" mark ① facing toward the clutch housing.



4. Install:
 - dowel pins
 - gasket **New**
 - clutch housing assembly

 **10 Nm (1.0 m · kg, 7.2 ft · lb)**

NOTE:


- Tighten the bolts in stages, using a criss-cross pattern.
- After tightening the bolts, check that the clutch housing assembly rotates smoothly.




EBS00319

CRANKCASE

TIMING CHAIN AND OIL FILTER



Order	Job/Part	Q'ty	Remarks
	Removing the timing chain and oil filter		Remove the parts in the order listed.
	Engine		Refer to "ENGINE REMOVAL".
	Cylinder head		Refer to "CYLINDER HEAD".
	Cylinder/piston		Refer to "CYLINDER AND PISTON".
	AC magneto rotor/starter wheel gear		Refer to "AC MAGNETO".
	Balancer driven gear/oil pump driven gear		Refer to "BALANCER GEARS AND OIL PUMP GEARS".
	Primary sheave assembly/secondary sheave assembly		Refer to "PRIMARY AND SECONDARY SHEAVES".
	Clutch carrier assembly		Refer to "CLUTCH".
1	Timing chain guide (intake side)	1	
2	Timing chain guide	1	
3	Timing chain	1	
4	Oil filter cartridge	1	




Order	Job/Part	Q'ty	Remarks
5	Speed sensor	1	For installation, reverse the removal procedure.
6	Dipstick	1	
7	Relief valve assembly	1	
8	Reverse switch	1	
9	Gear position switch	1	



EBS00320

CRANKCASE




Order	Job/Part	Q'ty	Remarks
	Separating the crankcase		Remove the parts in the order listed.
1	Shift lever cover	1	Refer to "INSTALLING THE SHIFT LEVER".
2	Gasket	1	
3	Dowel pin	1	
4	Shift lever 1	1	
5	Shift lever 2 assembly	1	
6	Shift drum stopper	1	Spring identification color: red
7	Stopper lever stopper	1	Spring identification color: yellow
8	Right crankcase	1	Refer to "SEPARATING THE CRANKCASE" and "ASSEMBLING THE CRANKCASE".
9	Dowel pin	2	
10	Left crankcase	1	
			For installation, reverse the removal procedure.




EBS00321

CRANKCASE BEARINGS



Order	Job/Part	Q'ty	Remarks
	Removing the crankcase bearings		Remove the parts in the order listed.
	Crankshaft/oil pump		Refer to "CRANKSHAFT AND OIL PUMP".
	Transmission		Refer to "TRANSMISSION".
	Middle drive shaft/middle driven shaft		Refer to "MIDDLE GEAR".
1	Collar	1	
2	O-ring	1	
3	Oil seal	1	
4	Bearing retainer	1	
5	Spacer	1	
6	Crank seal	2	
7	Bearing	9	
			For installation, reverse the removal procedure.



EBS00339


CHECKING THE BEARINGS

1. Check:
 - bearings
 - Clean and lubricate, then rotate the inner race with a finger.
 - Roughness → Replace.

EBS00338

CHECKING THE CRANKCASE

1. Thoroughly wash the case halves in a mild solvent.
2. Clean all the gasket mating surfaces and crankcase mating surfaces thoroughly.
3. Check:
 - crankcase
 - Cracks/damage → Replace.
 - oil delivery passages
 - Clogged → Blow out with compressed air.



EBS00342

ASSEMBLING THE CRANKCASE

1. Apply:
 - sealant ①
 - (to the mating surfaces of both case halves)



Yamaha bond No. 1215
90890-85505
(Three bond No.1215®)

NOTE:

Apply two coats of sealant to the area ① shown in the illustration.



2. Install:
 - dowel pins ②



3. Fit the right crankcase onto the left crankcase. Tap lightly on the case with a soft hammer.

CAUTION:

Before installing and torquing the crankcase holding bolts, be sure to check whether the transmission is functioning properly by manually rotating the shift drum in both directions.



4. Install:
 - lead holder
 - crankcase bolts
5. Tighten:
 - crankcase bolts
(follow the proper tightening sequence)


10 Nm (1.0 m · kg, 7.2 ft · lb)

- A Right crankcase
 B Left crankcase

NOTE:

Tighten the bolts in stages, using a crisscross pattern.

6. Apply:
 - 4-stroke engine oil
(to the crankshaft pin, bearing and oil delivery hole)
7. Check:
 - crankshaft and transmission operation
Unsmooth operation → Repair.

**INSTALLING THE SHIFT LEVER**

1. Install:
 - shift lever 2 assembly ①

14 Nm (1.4 m · kg, 10 ft · lb)

- shift lever 1 ②


NOTE:

When installing the shift lever 1, align the punch mark **a** on the shift lever 1 with the punch marks **b** on the shift lever 2.



EBS00326

CRANKSHAFT AND OIL PUMP




Order	Job/Part	Q'ty	Remarks
	Removing the crankshaft and oil pump		Remove the parts in the order listed.
	Crankcase		Separate. Refer to "CRANKCASE".
1	Oil pump	1	
2	Gasket	1	
3	Balancer	1	
4	Crankshaft	1	Refer to "REMOVING THE CRANKSHAFT" and "INSTALLING THE CRANKSHAFT". For installation, reverse the removal procedure.




EBS00327

OIL PUMP



Order	Job/Part	Q'ty	Remarks
	Disassembling the oil pump		Remove the parts in the order listed.
1	Oil pump housing cover	1	
2	Pin	1	
3	Oil pump shaft	1	
4	Oil pump inner rotor	1	
5	Oil pump outer rotor	1	
6	Oil pump housing	1	
			For assembly, reverse the disassembly procedure.




EBS00336

REMOVING THE CRANKSHAFT

1. Remove:
 - crankshaft ①
 - Use a crankcase separating tool ②.



Crankcase separating tool
90890-01135
Crankcase separator
YU-01135-B



EBS00331


CHECKING THE OIL PUMP

1. Check:
 - oil pump housing
 - oil pump housing cover
 - Cracks/wear/damage → Replace.
2. Measure:
 - inner-rotor-to-outer-rotor-tip clearance ①
 - outer-rotor-to-oil-pump-housing clearance ②
 - oil-pump-housing-to-inner-rotor-and-outer-rotor clearance ③
 - Out of specification → Replace the oil pump.

- ① Inner rotor
- ② Outer rotor
- ③ Oil pump housing



Inner-rotor-to-outer-rotor-tip clearance
 Less than 0.12 mm (0.0047 in)
 <Limit>: 0.20 mm (0.0079 in)
Outer-rotor-to-oil-pump-housing clearance
 0.090 ~ 0.170 mm
 (0.0035 ~ 0.0067 in)
 <Limit>: 0.24 mm (0.0094 in)
Oil-pump-housing-to-inner-rotor-and-outer-rotor clearance
 0.030 ~ 0.100 mm
 (0.0012 ~ 0.0039 in)
 <Limit>: 0.17 mm (0.0067 in)




3. Check:
 - oil pump operation
 - Rough movement → Repeat steps (1) and (2) or replace the defective part(s).



CHECKING THE OIL STRAINER

1. Check:
 - oil strainer
Damage → Replace.
Contaminants → Clean with engine oil.



EBS00360

CHECKING THE CRANKSHAFT

1. Measure:
 - crank width (a)
Out of specification → Replace the crankshaft.


	Crank width 74.95 ~ 75.00 mm (2.951 ~ 2.953 in)
--	--

2. Measure:
 - side clearance (b)
Out of specification → Replace the crankshaft.

	Big end side clearance 0.350 ~ 0.650 mm (0.0138 ~ 0.0256 in) <Limit>: 1.0 mm (0.04 in)
--	--

3. Measure:
 - runout (c)
Out of specification → Replace the crankshaft.

	Runout limit 0.030 mm (0.0012 in)
--	---




EBS00318

ASSEMBLING THE OIL PUMP

1. Install:
 - oil pump housing ①
 - oil pump outer rotor ②
 - oil pump inner rotor ③
 - oil pump shaft ④
 - pin ⑤

NOTE:

When installing the oil pump shaft ④ align the pin ⑤ with the groove ③ in the inner rotor ③.



EBS00362

INSTALLING THE CRANKSHAFT

1. Install:
 - crankshaft ①



Crankshaft installer pot ②

90890-01274

Installing pot

YU-90058

Pot installer

YU-90059

Crankshaft installer bolt ③

90890-01275

Bolt

YU-90060

Adapter (M16) ④

90890-04130

Adapter #13

YM-04059

Spacer (crankshaft installer) ⑤

90890-04081

Pot spacer

YM-91044

Spacer ⑥

90890-01309

Pot spacer

YU-90059

**NOTE:** _____

Hold the connecting rod at the Top Dead Center (TDC) with one hand while turning the nut of the installing tool with the other. Operate the installing tool until the crankshaft bottoms against the bearing.


CAUTION: _____

Apply engine oil to each bearing to protect the crankshaft against scratches and to make installation easier.




EBS00345

TRANSMISSION



Order	Job/Part	Q'ty	Remarks
	Removing the transmission		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
	Middle driven gear		Refer to "MIDDLE GEAR".
1	Shift drum	1	Refer to "ASSEMBLING THE SHIFT FORK ASSEMBLY". Refer to "REMOVING THE TRANSMISSION" and "INSTALLING THE TRANSMISSION".
2	Shift fork assembly	1	
3	Shift fork "R"	1	
4	Spring	1	
5	Shift fork "L"	1	
6	Shift fork guide bar	1	
7	Secondary shaft	1	
8	Drive axle assembly	1	
9	Reverse idle gear	1	
10	Reverse idle gear shaft	1	




Order	Job/Part	Q'ty	Remarks
11	Stopper lever	1	Refer to "REMOVING THE TRANSMISSION" and "INSTALLING THE TRANSMISSION". For installation, reverse the removal procedure.
12	Stopper lever shaft	1	




EBS00348


DRIVE AXLE



Order	Job/Part	Q'ty	Remarks
	Disassembling the drive axle assembly		Remove the parts in the order listed.
①	Washer	1	
②	Collar	1	
③	High wheel gear	1	
④	Washer	1	
⑤	Clutch dog	1	
⑥	Circlip	1	
⑦	Washer	1	
⑧	Collar	1	
⑨	Low wheel gear	1	
⑩	Washer	1	
⑪	Circlip	1	
⑫	Middle drive gear	1	
⑬	Circlip	1	




Order	Job/Part	Q'ty	Remarks
⑭	Washer	1	For assembly, reverse the disassembly procedure.
⑮	Bearing	1	
⑯	Reverse wheel gear	1	
⑰	Stopper wheel	1	
⑱	Drive axle	1	



EBS00351

CHECKING THE SHIFT DRUM

1. Check:
 - shift drum grooves
 - Scratches/wear/damage → Replace.




EBS00354

CHECKING THE TRANSMISSION

1. Measure:
 - drive axle runout
 - (with a centering device and dial gauge ①)
 - Out of specification → Replace the drive axle.



Drive axle runout limit
0.06 mm (0.0024 in)




2. Check:
 - transmission gears
 - Blue discoloration/pitting/wear → Replace the defective gear(s).
 - transmission gear dogs
 - Cracks/damage/rounded edges → Replace the defective gear(s).
3. Check:
 - transmission gear engagement
 - (each pinion gear to its respective wheel gear)
 - Incorrect → Reassemble the transmission axle assemblies.
4. Check:
 - transmission gear movement
 - Rough movement → Replace the defective part(s).
5. Check:
 - circlips
 - Bends/damage/looseness → Replace.




CHECKING THE SECONDARY SHAFT

1. Check:
 - gear teeth
Blue discoloration/pitting/wear → Replace.



CHECKING THE STOPPER LEVER AND STOPPER WHEEL




1. Check:
 - stopper lever pawl ①
Bends/damage/wear → Replace the stopper lever and stopper wheel as a set.
 - stopper wheel ②
Damage/wear → Replace the stopper wheel and stopper lever as a set.
 - stopper lever shaft ③
Bends/damage/wear → Replace.



ASSEMBLING THE SHIFT FORK ASSEMBLY

1. Install:
 - shift fork guide bar ①
 - shift fork "L" ②
 - spring ③
 - shift fork "R" ④
 - circlips ⑤ **New**

NOTE: _____
Install the shift forks with their "3B4" marks ⑥ facing each other.



EBS00356

INSTALLING THE TRANSMISSION

1. Install:

- stopper lever shaft
- stopper lever
- reverse idle gear ①
- drive axle assembly ②
- secondary shaft ③
- shift fork assembly ④
- shift drum ⑤

NOTE:

Install the shift forks ⑥ with the "L" mark ① and "R" mark ② facing towards the left and right sides of the crankcase respectively.

2. Check:

- shift operation
- Unsmooth operation → Repair.

NOTE:


- Oil each gear and bearing thoroughly.
- Before assembling the crankcase, make sure that the transmission is in neutral and that the gears turn freely.



EBS00363

MIDDLE GEAR

MIDDLE DRIVE SHAFT




Order	Job/Part	Q'ty	Remarks
	Removing the middle drive shaft		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
1	Bearing housing	1	Refer to "REMOVING THE MIDDLE DRIVE SHAFT" and "INSTALLING THE MIDDLE DRIVE SHAFT".
2	Middle drive pinion gear nut	1	
3	Middle drive pinion gear	1	
4	Middle drive gear shim	*	
5	Middle drive shaft	1	
6	Bearing retainer	2	
7	Bearing	1	
8	Circlip	1	
9	Middle driven gear	1	
			For installation, reverse the removal procedure.




EBS00364

MIDDLE DRIVEN SHAFT



Order	Job/Part	Q'ty	Remarks
	Removing the middle driven shaft		
	Crankcase		Remove the parts in the order listed. Separate. Refer to "CRANKCASE".
1	Front drive shaft coupling gear nut (middle gear side)	1	Refer to "REMOVING THE MIDDLE DRIVEN SHAFT" and "INSTALLING THE MIDDLE DRIVEN SHAFT".
2	Front drive shaft coupling gear (middle gear side)	1	
3	Middle driven pinion gear assembly	1	
4	Rear drive shaft coupling gear nut (middle gear side)	1	
5	Rear drive shaft coupling gear (middle gear side)	1	
6	Bearing housing	1	
7	O-ring	1	
8	Middle driven gear shim	*	
9	Middle driven pinion gear	1	



Order	Job/Part	Q'ty	Remarks
10	Bearing	1	Refer to "REMOVING THE MIDDLE DRIVEN SHAFT" and "INSTALLING THE MIDDLE DRIVEN SHAFT".
11	Middle driven pinion gear bearing retainer	1	
12	Bearing	1	
13	Middle driven shaft bearing retainer	1	
14	Bearing	1	
15	Middle driven shaft	1	For installation, reverse the removal procedure.




EBS00365

REMOVING THE MIDDLE DRIVE SHAFT

1. Straighten:

- punched portion of the middle drive pinion gear nut



2. Loosen:


- middle drive pinion gear nut (1)

NOTE:

Secure the middle drive shaft in the vise with a clean rag.

3. Remove:

- middle drive pinion gear nut
- middle drive pinion gear
- shim(s)




4. Remove:

- middle driven gear (1)
- circlip
- middle drive shaft (2)

NOTE:

Press the middle drive shaft end and remove the middle driven gear.



EBS01020

REMOVING THE MIDDLE DRIVEN SHAFT

1. Remove:


- front drive shaft coupling gear nut (middle gear side) ①
- washer
- front drive shaft coupling gear (middle gear side) ②

NOTE:

Use the coupling gear/middle shaft tool ③ to hold the coupling gear.



Coupling gear/middle shaft tool
90890-01229
Gear holder
YM-01229



2. Remove:


- rear drive shaft coupling gear nut (middle gear side) ①
- washer
- rear drive shaft coupling gear (middle gear side) ②

NOTE:

Use the coupling gear/middle shaft tool ③ to hold the coupling gear.



Coupling gear/middle shaft tool
90890-01229
Gear holder
YM-01229



3. Remove:

- bearing housing assembly ①




- a. Clean the outside of the bearing housing assembly.
- b. Place the bearing housing assembly onto a hydraulic press.



CAUTION:

- Never directly press the middle driven pinion gear end with a hydraulic press, this will result in damage to the middle driven pinion gear thread.
- Install a suitable socket ② on the middle driven pinion gear end to protect the thread from damage.

c. Press the middle driven pinion gear end and remove the bearing housing.



4. Remove:
- middle driven pinion gear bearing retainer
 - bearing



- Attach the folded rag ①.
- Secure the bearing housing edge in the vise.
- Attach the bearing retainer wrench ②.




**Bearing retainer wrench
90890-04128
Middle gear bearing retainer
YM-04128**

CAUTION:

The middle driven pinion gear bearing retainer has left-handed threads. To loosen the retainer, turn it clockwise.

- Remove the bearing retainer and bearing.





5. Remove:

- oil seal ①
- middle driven shaft bearing retainer ②

NOTE: _____



Attach the ring nut wrench ③.



Ring nut wrench
90890-01430, YM-38404

CAUTION: _____

The middle driven shaft bearing retainer has left-handed threads. To loosen the retainer turn it clockwise.



6. Remove:

- middle driven shaft ①
(with bearing)

EBS01021


CHECKING THE PINION GEARS

1. Check:

- drive pinion gear teeth
- driven pinion gear teeth
Pitting/galling/wear → Replace.

2. Check:

- O-ring
Damage → Replace.
- bearings
Pitting/damage → Replace.




ⓔ = a numeral (usually a decimal number) on the left crankcase specifies a thickness of “9.0”






Example:

- 1) If the bearing housing is marked “-02”,
..... ⓐ is 0.58
- 2) ⓑ is 17.0
- 3) ⓒ is 55.0
- 4) If the right crankcase is marked “64.97”,
..... ⓓ is 64.97
- 5) If the left crankcase is marked “9.01”,
..... ⓔ is 9.01
- 6) Therefore, the shim thickness is 1.40 mm.
“A” = 9.01 + 64.97 – 17.0 – 55.0 – 0.58
= 1.40
- 7) Round off hundredths digit and select appropriate shim(s). In the example above, the calculated shim thickness is 1.40 mm. The chart instructs you, however, to round off 0 to 0.

Hundredths	Round value
0, 1, 2	0
3, 4, 5, 6, 7	5
8, 9	10

Shims are supplied in the following thickness.

	Middle drive pinion gear shim		
Thickness (mm)	0.50	0.70	1.00
	0.55	0.80	
	0.60	0.90	



- c. To find shim thickness "B" use the following formula:

$$\text{Middle driven pinion gear shim thickness} \\ \text{"B"} = f - g + h - i - j - 0.05$$

Where:

- ⓕ = a numeral (usually a decimal number) on the bearing housing is either added to or subtracted from "77.5"

NOTE:

After replacing any part in the middle driven pinion gear assembly, the overall length of the assembly will change. Therefore, be sure to measure distance ⓕ to select the correct middle driven pinion gear shim thickness.

- ⓖ = a numeral (usually a decimal number) on the middle driven pinion gear is either added to or subtracted from "49.0"

- ⓓ = a numeral (usually a decimal number) on the middle driven pinion gear is either added to or subtracted from "80.5"


- ⓔ = a numeral (usually a decimal number) on the left crankcase specifies a thickness of "99.98"

- ⓖ = a numeral (usually a decimal number) on the right crankcase specifies a thickness of "8.12"

Example:

- 1) If the bearing housing is marked "+03",
..... ⓕ is 77.53
- 2) If the driven pinion gear is marked "+0",
..... ⓖ is 49.0
- 3) If the driven pinion gear is marked "-10",
..... ⓓ is 80.40
- 4) If the left crankcase is marked "99.99",
..... ⓔ is 99.99
- 5) If the right crankcase is marked "8.17",
..... ⓖ is 8.17
- 6) Therefore, the shim thickness is 0.72 mm.


$$\begin{aligned} \text{"B"} &= 77.53 - 49.0 + 80.40 - 99.99 - 8.17 - \\ &\quad 0.05 \\ &= 0.72 \end{aligned}$$




7) Round off hundredth digit and select appropriate shim(s). In the example above, the calculated shim thickness is 0.72 mm. The chart instructs you, however, to round off 2 to 0.

Hundredths	Round value
0, 1, 2	0
3, 4, 5, 6, 7	5
8, 9	10


Shims are supplied in the following thickness.


 Middle drive pinion gear shim	
Thickness (mm)	0.10 0.40
	0.15 0.50
	0.20 0.60
	0.30




INSTALLING THE BEARING AND OIL SEALS

1. Install:
 - bearing ①
 - oil seal ②
 - oil seal ③



	Installed depth of bearing ①
	0.9 ~ 1.4 mm (0.035 ~ 0.055 in)
	Installed depth of oil seal ②
	1.0 ~ 1.5 mm (0.039 ~ 0.059 in)
	Installed depth of oil seal ③
	1.0 ~ 1.5 mm (0.039 ~ 0.059 in)


- ④ Middle drive pinion gear bearing retainer
- ⑤ Bearing housing
- ⑥ Middle driven shaft bearing retainer
- ⑦ Crankcase




3. Install:
- middle driven gear shim(s) ①
 - bearing housing

NOTE:

Install the shim(s) so that the tabs are positioned as shown in the illustration.



4. Install:
- rear drive shaft coupling gear (middle gear side) ①
 - washer
 - rear drive shaft coupling gear nut (middle gear side) ②


 **150 Nm (15.0 m · kg, 110 ft · lb)**

NOTE:


Use the coupling gear/middle shaft tool ③ to hold the coupling gear.



**Coupling gear/middle shaft tool
90890-01229
Gear holder
YM-01229**



5. Install:
- front drive shaft coupling gear (middle gear side) ①
 - washer
 - front drive shaft coupling gear nut (middle gear side) ②

 **115 Nm (11.5 m · kg, 85 ft · lb)**

NOTE:

Use the coupling gear/middle shaft tool ③ to hold the coupling gear.



**Coupling gear/middle shaft tool
90890-01229
Gear holder
YM-01229**



-
- e. If the gear lash is incorrect, adjust the gear lash by middle driven pinion gear shims and/or middle drive pinion gear shim(s).






EBS00125


COOLING SYSTEM

RADIATOR




5

Order	Job/Part	Q'ty	Remarks
	Removing the radiator		Remove the parts in the order listed.
	Front fenders		Refer to "FRONT FENDERS AND FRONT GRILL" in chapter 3.
	Front guard		Refer to "FRONT CARRIER AND FRONT GUARD" in chapter 3.
	Left footrest board		Refer to "FOOTREST BOARDS" in chapter 3.
	Air filter case		Refer to "AIR FILTER CASE" in chapter 3.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" in chapter 3.
1	Radiator fan motor coupler	1	Disconnect.
2	Radiator fan breather hose	1	
3	Coolant reservoir hose	1	
4	Coolant reservoir breather hose	1	



Order	Job/Part	Q'ty	Remarks
5	Coolant reservoir cap	1	For installation, reverse the removal procedure.
6	Coolant reservoir	1	
7	Fast idle plunger outlet hose	1	
8	Radiator outlet hose	1	
9	Radiator inlet hose	1	
10	Radiator bracket	1	
11	Radiator	1	
12	Radiator fan	1	



EBS00127

CHECKING THE RADIATOR

1. Check:

- radiator fins

Obstruction → Clean.

Apply compressed air to the rear of the radiator.

Damage → Repair or replace.

NOTE:

Straighten any flattened fins with a thin, flat-head screwdriver.

2. Check:


- radiator hoses

Cracks/damage → Replace.

3. Measure:

- radiator cap opening pressure

Below the specified pressure → Replace the radiator cap.



Radiator cap opening pressure

93.3 ~ 122.7 kPa

(0.933 ~ 1.227 kg/cm²,

13.27 ~ 17.45 psi)



- a. Install the radiator cap tester ① and radiator cap tester adapter ② to the radiator cap ③.



Radiator cap tester

90890-01325

Radiator pressure tester

YU-24460-01

Radiator cap tester adapter

90890-01352

Radiator pressure tester adapter

YU-33984

- b. Apply the specified pressure for ten seconds and make sure there is no drop in pressure.



4. Check:

- radiator fan

Damage → Replace.

Malfunction → Check and repair.

Refer to “COOLING SYSTEM” in chapter 9.



EBS00128

INSTALLING THE RADIATOR

1. Fill:

- cooling system
(with the specified amount of the recommended coolant)
Refer to “CHANGING THE COOLANT” in chapter 3.

2. Check:

- cooling system
Leaks → Repair or replace any faulty part.


3. Measure:

- radiator cap opening pressure
Below the specified pressure → Replace the radiator cap.
Refer to “CHECKING THE RADIATOR”.



EBS00129

THERMOSTAT




Order	Job/Part	Q'ty	Remarks
	Removing the thermostat		Remove the parts in the order listed.
	Air filter case		Refer to "AIR FILTER CASE" in chapter 3.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" in chapter 3.
1	Radiator inlet hose	1	Disconnect.
2	Thermostat cover	1	
3	Thermostat	1	
4	Coolant temperature sensor	1	
5	Copper washer	1	
			For installation, reverse the removal procedure.




EBS00134


WATER PUMP



Order	Job/Part	Q'ty	Remarks
	Removing the water pump		Remove the parts in the order listed.
	Left footrest board		Refer to "FOOTREST BOARDS" in chapter 3.
	Left front fender		Refer to "FRONT FENDERS AND FRONT GRILL" in chapter 3.
	AC magneto cover		Refer to "AC MAGNETO" in chapter 4.
	Coolant		Drain. Refer to "CHANGING THE COOLANT" in chapter 3.
1	Radiator outlet hose	1	Disconnect.
2	Water jacket joint	1	
3	Water pump outlet hose	1	
4	Water pump outlet pipe	1	
5	Water pump breather hose	1	
6	Water pump housing	1	



Order	Job/Part	Q'ty	Remarks
7	Gasket	1	For installation, reverse the removal procedure.
8	Circlip	1	
9	Impeller shaft	1	
10	Water pump seal	1	
11	Bearing	1	
12	Oil seal	1	




EBS00138

DISASSEMBLING THE WATER PUMP

1. Remove:
 - water pump seal ①

NOTE: _____

Tap out the water pump seal from the inside of the AC magneto cover ②.



2. Remove:
 - bearing ①
 - oil seal ②


NOTE: _____

Tap out the bearing and oil seal from the outside of the AC magneto cover ③.

EBS00139

CHECKING THE WATER PUMP

1. Check:
 - water pump housing
 - impeller shaft
 - Cracks/damage/wear → Replace.
2. Check:
 - water jacket
 - water jacket outlet hose
 - water jacket outlet pipe
 - Cracks/damage/wear → Replace.
 - bearing
 - Rough movement → Replace.



EBS00140

ASSEMBLING THE WATER PUMP


1. Install:
- oil seal ① **New**
(into the AC magneto cover ②)

NOTE: _____

- Before installing the oil seal, apply tap water or coolant onto its out surface.
- Install the oil seal with a socket ③ that matches its outside diameter.



Installed depth of oil seal ①
8.1 ~ 8.7 mm (0.32 ~ 0.34 in)



2. Install:
- water pump seal ① **New**
(into the AC magneto cover ②)

CAUTION: _____

Never lubricate the water pump seal surface with oil or grease.


NOTE: _____

Install the water pump seal with the special tools.



Mechanical seal installer ③
90890-04132
Water pump seal installer
YM-33221-A
Middle driven shaft bearing driver
④
90890-04058
Bearing driver 40 mm
YM-04058

Ⓐ Push down.



3. Measure:

- impeller shaft tilt
Out of specification → Replace.

CAUTION:

Make sure the rubber damper and rubber damper holder are flush with the impeller.



**Impeller shaft tilt limit
0.15 mm (0.006 in)**

- ① Straightedge
- ② Impeller shaft




EAS00894


FUEL INJECTION SYSTEM

FUEL INJECTION SYSTEM

- | | |
|----------------------------------|------------------------------|
| ① ECU (engine control unit) | ⑧ Fuel injector |
| ② Lean angle sensor | ⑨ Fuel pump |
| ③ Fuel injection system relay | ⑩ Speed sensor |
| ④ Engine trouble warning light | ⑪ Crankshaft position sensor |
| ⑤ Intake air pressure sensor | ⑫ Coolant temperature sensor |
| ⑥ TPS (throttle position sensor) | ⑬ Spark plug |
| ⑦ Intake air temperature sensor | ⑭ Ignition coil |










- ① Crankshaft position sensor
- ④ Main switch
- ⑥ Main fuse
- ⑧ Battery
- ⑨ Fuel injection system fuse
- ⑱ Fuel injection system relay
- ⑳ ECU (engine control unit)
- ㉑ Ignition coil
- ㉒ Spark plug
- ㉔ Fuel injector
- ㉕ Intake air temperature sensor
- ㉖ Coolant temperature sensor
- ㉗ Speed sensor
- ㉘ TPS (throttle position sensor)
- ㉙ Intake air pressure sensor
- ㉚ Lean angle sensor
- ㉛ Multifunction meter
- ㉜ Engine trouble warning light
- ㉝ Fuel pump
- ㉞ Engine stop switch
- ㉟ Ignition fuse



ECU SELF-DIAGNOSTIC FUNCTION

The ECU is equipped with a self-diagnostic function in order to ensure that the fuel injection system is operating normally. If this function detects a malfunction in the system, it immediately operates the engine under substitute characteristics and illuminates the engine trouble warning light to alert the rider that a malfunction has occurred in the system. Once a malfunction has been detected, a fault code is stored in the memory of the ECU.



① Engine trouble warning light

- To inform the rider that the fuel injection system is not functioning, the engine trouble warning light flashes when the start switch is being pushed to start the engine.
- If a malfunction is detected in the system by the self-diagnostic function, the ECU provides an appropriate substitute characteristic operation, and alerts the rider of the detected malfunction by illuminating the engine trouble warning light.
- After the engine has been stopped, the lowest fault code number appears on the odometer/tripmeter LCD. Once a fault code has been displayed, it remains stored in the memory of the ECU until it is deleted.

Engine trouble warning light indication and fuel injection system operation

Warning light indication	ECU operation	Fuel injection operation	Vehicle operation
Flashing*	Warning provided when unable to start engine	Operation stopped	Cannot be operated
Remains on	Malfunction detected	Operated with substitute characteristics in accordance with the description of the malfunction	Can or cannot be operated depending on the fault code

*The warning light flashes when any one of the conditions listed below is present and the start switch is pushed:

- | | | | |
|-----|---------------------------------------|-----|---|
| 12: | Crankshaft position sensor | 41: | Lean angle sensor (open or short-circuit) |
| 30: | Lean angle sensor (latch up detected) | 50: | ECU internal malfunction (memory check error) |



EAS27380

SELF-DIAGNOSTIC FUNCTION TABLE

If the ECU detects an abnormal signal from a sensor while the vehicle is being driven, the ECU illuminates the engine trouble warning light and provides the engine with alternate operating instructions that are appropriate for the type of malfunction.

When an abnormal signal is received from a sensor, the ECU processes the specified values that are programmed for each sensor in order to provide the engine with alternate operating instructions that enable the engine to continue to operate or stop operating, depending on the conditions.

Self-diagnostic function table

Fault code No.	Item	Symptom	Able / unable to start	Able / unable to drive
12	Crankshaft position sensor	No normal signals are received from the crankshaft position sensor.	Unable	Unable
13	Intake air pressure sensor (open or short circuit)	Intake air pressure sensor: open or short circuit detected.	Able	Able
14	Intake air pressure sensor (hose line)	Intake air pressure sensor: hose system malfunction (clogged or detached hose).	Able	Able
15	Throttle position sensor (open or short circuit)	Throttle position sensor: open or short circuit detected.	Able	Able
16	Throttle position sensor	Stuck throttle position sensor detected.	Able	Able
21	Coolant temperature sensor	Coolant temperature sensor: open or short circuit detected.	Able	Able
22	Intake air temperature sensor (open or short circuit)	Intake air temperature sensor: open or short circuit detected.	Able	Able
30	Lean angle sensor (latch up detected)	The vehicle has overturned.	Unable	Unable
33	Ignition coil (faulty ignition)	Malfunction detected in the primary wire of ignition coil.	Unable	Unable
39	Injector (open circuit)	Injector: open circuit detected.	Unable	Unable
41	Lean angle sensor (open or short circuit)	Lean angle sensor: open or short circuit detected.	Unable	Unable
42	Speed sensor	No normal signals are received from the speed sensor.	Able	Able
43	Fuel system voltage (monitoring voltage)	The ECU is unable to monitor the battery voltage (an open or short circuit in the line to the ECU).	Able	Able
44	Error in writing the amount of CO adjustment on EEPROM	Error is detected while reading or writing on EEPROM (CO adjustment value).	Able	Able
46	Vehicle system power supply (Monitoring voltage)	Power supply is not normal.	Able	Able
50	ECU internal malfunction (memory check error)	Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the meter).	Unable	Unable


Communication error with the meter

Fault code No.	Item	Symptom	Able / unable to start	Able / unable to drive
Er-1	ECU internal malfunction (output signal error)	No signals are received from the ECU.	Unable	Unable
Er-2	ECU internal malfunction (output signal error)	No signals are received from the ECU within the specified duration.	Unable	Unable
Er-3	ECU internal malfunction (output signal error)	Data from the ECU cannot be received correctly.	Unable	Unable
Er-4	ECU internal malfunction (input signal error)	Non-registered data has been received from the meter.	Unable	Unable



EAS00904

TROUBLESHOOTING CHART




* Operated when the engine trouble warning light is on.



EAS00905

DIAGNOSTIC MODE

It is possible to monitor the sensor output data or check the activation of actuators without connecting the measurement equipment by simply switching the meter indication from the normal mode to the diagnostic monitoring mode.




Setting the diagnostic mode

1. Turn the main switch to "OFF" and set the engine stop switch to "OFF".
2. Disconnect the wire harness coupler from the fuel pump.
3. Simultaneously press and hold the "SELECT" and "RESET" buttons, turn the main switch to "ON", and continue to press the buttons for 8 seconds or more.

NOTE:

- All displays on the meter disappear.
- "DIAG" appears on the LCD meter.



4. Simultaneously press the "SELECT" and "RESET" buttons for 2 seconds or more to execute the selection.
5. Select the diagnostic code number that applies to the item that was verified with the fault code number by pressing the "SELECT" and "RESET" buttons.

NOTE:

- The diagnostic code number appears on the LCD meter (01-70).
- To decrease the selected diagnostic code number, press the "RESET" button. Press the "RESET" button for 1 second or longer to automatically decrease the diagnostic code numbers.
- To increase the selected diagnostic code number, press the "SELECT" button. Press the "SELECT" button for 1 second or longer to automatically increase the diagnostic code numbers.



6. Verify the operation of the sensor or actuator.
 - Sensor operation
The data representing the operating conditions of the sensor appears on the LCD meter.
 - Actuator operation
Set the engine stop switch to “ON” to operate the actuator.
- * If the engine stop switch is set to “ON”, set it to “OFF”, and then set it to “ON” again.
7. Turn the main switch to “OFF” to cancel the diagnostic mode.

NOTE: _____
To perform a reliable diagnosis, make sure to turn off the power supply before every check and then start right from the beginning.



Diagnostic code table

Fault code No.	Symptom	Probable cause of malfunction	Diagnostic code No.
12	No normal signals are received from the crankshaft position sensor.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective crankshaft position sensor. • Malfunction in pickup rotor. • Malfunction in ECU. • Improperly installed sensor. 	—
13	Intake air pressure sensor: open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective intake air pressure sensor. • Malfunction in ECU. 	D03
14	Intake air pressure sensor: hose system malfunction (clogged or detached hose).	<ul style="list-style-type: none"> • Intake air pressure sensor hose is detached, clogged, kinked, or pinched. • Malfunction in ECU. 	D03
15	Throttle position sensor: open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire sub lead. • Open or short circuit in wire harness. • Defective throttle position sensor. • Malfunction in ECU. • Improperly installed throttle position sensor. 	D01
16	Stuck throttle position sensor detected.	<ul style="list-style-type: none"> • Stuck throttle position sensor. • Malfunction in ECU. 	D01
21	Coolant temperature sensor: open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective coolant temperature sensor. • Malfunction in ECU. • Improperly installed coolant temperature sensor. 	D06
22	Intake air temperature sensor: open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective intake air temperature sensor. • Malfunction in ECU. • Improperly installed intake air temperature sensor. 	D05
30	The vehicle has overturned.	<ul style="list-style-type: none"> • Overturned. • Malfunction in ECU. 	D08
33	Malfunction detected in the primary lead of the ignition coil.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Malfunction in ignition coil. • Malfunction in ECU. • Malfunction in a component of ignition cut-off circuit system. 	D30 D32
39	Open circuit detected in a injector.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Improperly installed injector. • Defective injector. 	D36
41	Lean angle sensor: open or short circuit detected.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Defective lean angle sensor. • Malfunction in ECU. 	D08
42	No normal signals are received from the speed sensor.	<ul style="list-style-type: none"> • Open circuit in wire harness. • Defective speed sensor. • Malfunction in vehicle speed sensor detected. • Malfunction in the engine side of the neutral switch. • Malfunction in ECU. 	D07
43	Power supply to the injector and fuel pump is not normal.	<ul style="list-style-type: none"> • Open or short circuit in wire harness. • Malfunction in ECU. 	D09
44	Error is detected while reading or writing on EEPROM (CO adjustment value).	<ul style="list-style-type: none"> • Malfunction in ECU. (The CO adjustment value is not properly written on or read from the internal memory). 	D60
46	Power supply to the fuel injection system is not normal.	<ul style="list-style-type: none"> • Malfunction in the charging system. Refer to "CHARGING SYSTEM" in chapter 9. 	—
50	Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the LCD of the meter.)	<ul style="list-style-type: none"> • Malfunction in ECU. (The program and data are not properly written on or read from the internal memory.) 	—



Sensor operation table

Diagnostic code No.	Item	Meter display	Checking method
D01	Throttle angle • Fully closed position • Fully opened position	15 ~ 20 95 ~ 100	Check with throttle fully closed. Check with throttle fully open.
D03	Pressure difference (atmospheric pressure and intake air pressure)	Displays the intake air pressure.	Set the engine stop switch to "RUN", then operate the throttle while pushing the start switch. (If the display value changes, the performance is OK.)
D05	Intake air temperature	Displays the intake air temperature.	Compare the actually measured intake air temperature with the meter.
D06	Coolant temperature	Displays the coolant temperature.	Compare the actually measured coolant temperature with the meter.
D07	Vehicle speed pulse	0 ~ 999	Check that the number increases when the rear wheel is rotated. The number is cumulative and does not reset each time the wheel is stopped.
D08	Lean angle sensor • Upright • Overturned	0.4 ~ 1.4 3.7 ~ 4.4	Remove the lean angle sensor and incline it more than 65 degrees.
D09	Fuel system voltage (battery voltage)	Approximately 12.0	Set the engine stop switch to "RUN", and then compare with the actually measured battery voltage. (If the battery voltage is lower, perform recharging.)
D21	Neutral switch • Neutral • In gear	ON OFF	Shift the transmission.
D60	EEPROM fault code display • No history • History exists	00 01	—
D61	Malfunction history code display • No history • History exists	00 Fault codes 12-50 • (If more than one code number is detected, the display alternates every two seconds to show all the detected code numbers. When all code numbers are shown, the display repeats the same process.)	—
D62	Malfunction history code erasure • No history • History exists	0 Up to 16 fault codes	— To erase the history, set the engine stop switch to "OFF" and then to "RUN".
D70	Control number	00 ~ 255	—



Actuator operation table

- Actuator operation

Set the engine stop switch to “OFF” and then to “RUN”.

Diagnosis code No.	Item	Actuation	Checking method
D30	Ignition coil	Actuates the ignition coil five times in one-second intervals. The engine trouble warning light also flashes five times.	Check the spark five times. • Connect an ignition checker.
D36	Injector	Actuates the injector five times in one-second intervals.	Check the operating sound of the injector five times.
D50	Fuel pump relay	Actuates the fuel pump relay five times in one-second intervals. The engine trouble warning light also flashes five times. (The engine trouble warning light is OFF when the relay is ON, and the engine trouble warning light is ON when the relay is OFF).	Check the operating sound of the fuel pump relay five times.
D51	Radiator fan motor relay	Actuates the radiator fan motor relay and illuminates the engine trouble warning light five cycles (5 seconds per cycle—2 seconds ON, 3 seconds OFF). (ON 2 seconds, OFF 3 seconds)	Check the operating sound of the radiator fan motor relay five times.

EAS00908

TROUBLESHOOTING DETAILS

This section describes the countermeasures per fault code number displayed on the meter. Check and service the items or components that are the probable cause of the malfunction following the order given.

After the check and service of the malfunctioning part has been completed, reset the meter display according to the “Reinstatement method”.

Fault code No.:

Fault code number displayed on the meter when the engine failed to work normally.

Refer to “Diagnostic code table”.

Diagnostic code No.:

Diagnostic code number to be used when the diagnostic mode is operated. Refer to “DIAGNOSTIC MODE”.



Fault code No.	12	Symptom	No normal signals are received from the crankshaft position sensor.	
Diagnostic code No.	—	—		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of crankshaft position sensor.		Check for looseness or pinching.	Cranking the engine.
2	Connections <ul style="list-style-type: none"> • Crankshaft position sensor coupler • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	
3	Open or short circuit in wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between the crankshaft position sensor coupler and ECU coupler. (gray-gray) (black/blue-black/blue) 	
4	Defective crankshaft position sensor.		<ul style="list-style-type: none"> • Replace if defective. Refer to "IGNITION SYSTEM" in chapter 9. 	



Fault code No.	13	Symptom	Intake air pressure sensor: open or short circuit detected.	
Diagnostic code No.	D03	Intake air pressure sensor		
Order	Item/components and probable cause	Check or maintenance job		Reinstatement method
1	Connections <ul style="list-style-type: none"> • Intake air pressure sensor coupler • Main wire harness-ECU coupler 	<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 		Turning the main switch to "ON".
2	Open or short circuit in wire harness.	<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between intake air pressure sensor coupler and ECU coupler (black/blue–black/blue) (pink–pink) (blue–blue) 		
3	Defective intake air pressure sensor.	<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D03) • Replace if defective. Refer to "CHECKING THE INTAKE AIR PRESSURE SENSOR". 		



Fault code No.	14	Symptom	Intake air pressure sensor: hose system malfunction (clogged or detached hose).	
Diagnostic code No.	D03	Intake air pressure sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Intake air pressure sensor hose		<ul style="list-style-type: none"> • Check the intake air pressure sensor hose condition. • Repair or replace the sensor hose. 	Starting the engine and operating it at idle.
2	Intake air pressure sensor malfunction at intermediate electrical potential.		<ul style="list-style-type: none"> • Check and repair the connection. • Replace it if there is a malfunction. 	
3	Connections <ul style="list-style-type: none"> • Intake air pressure sensor coupler • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	
4	Defective intake air pressure sensor.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D03) • Replace if defective. Refer to "CHECKING THE INTAKE AIR PRESSURE SENSOR". 	



Fault code No.	15	Symptom	Throttle position sensor: open or short circuit detected.	
Diagnostic code No.	D01	Throttle position sensor		
Order	Item/components and probable cause	Check or maintenance job	Reinstatement method	
1	Installed condition of throttle position sensor.	<ul style="list-style-type: none"> • Check for looseness or pinching. • Check that the sensor is installed in the specified position. 	Turning the main switch to "ON".	
2	Connections <ul style="list-style-type: none"> • Throttle position sensor coupler • Main wire harness-ECU coupler 	<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 		
3	Open or short circuit in wire harness.	<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between throttle position sensor coupler and ECU coupler (blue-blue) (yellow-yellow) (black/blue-black/blue) 		
4	Throttle position sensor lead wire open circuit output voltage check.	<ul style="list-style-type: none"> • Check for open circuit and replace the throttle position sensor. (yellow-black/blue) 		
5	Defective throttle position sensor.	<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D01) • Replace if defective. Refer to "CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR". 		



Fault code No.	16	Symptom	Stuck throttle position sensor detected.	
Diagnostic code No.		D01	Throttle position sensor	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of throttle position sensor.		<ul style="list-style-type: none"> • Check the installed area for looseness or pinching. • Check that the throttle position sensor is installed in the specified position. Refer to "CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR".	Reinstated by starting the engine, operating it at idle, and then racing it.
2	Defective throttle position sensor.		<ul style="list-style-type: none"> • Execute the diagnostic monitoring mode. (Code No.D01) • Replace if defective. Refer to "CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR".	

Fault code No.	21	Symptom	Coolant temperature sensor: open or short circuit detected.	
Diagnostic code No.		D06	Coolant temperature sensor	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of coolant temperature sensor.		Check the installed area for looseness or pinching.	Turning the main switch to "ON".
2	Connections <ul style="list-style-type: none"> • Coolant temperature sensor coupler • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may have pulled out. • Check the locking condition of the coupler. If there is a malfunction, repair it and connect the coupler securely.	
3	Open or short circuit in wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between coolant temperature sensor coupler and ECU coupler. (black/blue-black/blue) (green/yellow-green/yellow) 	
4	Defective coolant temperature sensor.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D06) • Replace if defective. Refer to "SIGNALING SYSTEM" in chapter 9.	



Fault code No.	22	Symptom	Intake air temperature sensor: open or short circuit detected.	
Diagnostic code No.	D05	Intake air temperature sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Installed condition of air temperature sensor.		Check for looseness or pinching.	Turning the main switch to "ON".
2	Connections <ul style="list-style-type: none"> • Intake air temperature sensor coupler • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	
3	Open or short circuit in wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between intake air temperature sensor coupler and ECU coupler (brown/white–brown/white) (black/blue–black/blue) 	
4	Defective air temperature sensor.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D05) • Replace if defective. Refer to "CHECKING THE INTAKE AIR TEMPERATURE SENSOR". 	



Fault code No.	30	Symptom	The vehicle has overturned.	
Diagnostic code No.	D08	Lean angle sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	The vehicle has overturned.		Raise the vehicle upright.	Turning the main switch to "ON" (however, the engine cannot be restarted unless the main switch is first turned "OFF").
2	Installed condition of the lean angle sensor.		Check for looseness or pinching.	
3	Connections <ul style="list-style-type: none"> • Lean angle sensor coupler • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	
4	Defective lean angle sensor.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D08) • Replace if defective. Refer to "IGNITION SYSTEM" in chapter 9.	



Fault code No.	33	Symptom	Malfunction detected in the primary lead of the ignition coil.	
Diagnostic code No.	D30	Ignition coil		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connections <ul style="list-style-type: none"> • Ignition coil connector (primary coil side) • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the connector and coupler for any pins that may be pulled out. • Check the locking condition of the connector and coupler. • If there is a malfunction, repair it and connect the coupler or connector securely. 	Starting the engine and operating it at idle.
2	Open or short circuit in wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between ignition coil connector and ECU coupler. (orange–orange) • Between ignition coil connector and left handlebar switch coupler. (red/black–red/black) 	
3	Defective ignition coil.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D30) • Test the primary and secondary coils for continuity. • Replace if defective. Refer to “IGNITION SYSTEM” in chapter 9.	



Fault code No.	39	Symptom	Open circuit detected in a injector.	
Diagnostic code No.	D36	Injector		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connections <ul style="list-style-type: none"> • Injector coupler • Main wire harness-ECU coupler • Main wire harness fuel pump coupler 		<ul style="list-style-type: none"> • Check the couplers for any pins that may be pulled out. • Check the locking condition of the couplers. • If there is a malfunction, repair it and connect the coupler securely. 	Cranking the engine. (Connect the fuel injector coupler.)
2	Open or short circuit in wire harness and/or sub-wire harness 2.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between injector coupler and ECU coupler. (red/blue-red/blue) (red/black-red/black) 	
3	Defective injector.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D36) • Replace if defective. Refer to "CHECKING THE FUEL INJECTOR". 	



Fault code No.	41	Symptom	Lean angle sensor: open or short circuit detected.	
Diagnostic code No.	D08	Lean angle sensor		
Order	Item/components and probable cause	Check or maintenance job	Reinstatement method	
1	Connections <ul style="list-style-type: none"> • Lean angle sensor coupler • Main wire harness-ECU coupler 	<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	Turning the main switch to "ON".	
2	Open or short circuit in lead wire.	<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between lean angle sensor coupler and ECU coupler. (blue-blue) (yellow/green-yellow/green) (black/blue-black/blue) 		
3	Defective lean angle switch.	<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D08) • Replace if defective. Refer to "IGNITION SYSTEM" in chapter 9. 		



Fault code No.	42	Symptom	No normal signals are received from the speed sensor.	
Diagnostic code No.	D07	Speed sensor		
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connections <ul style="list-style-type: none"> • Speed sensor coupler • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	Starting the engine, and activating the vehicle speed sensor by operating the vehicle at 20 to 30 km/h.
2	Open or short circuit in speed sensor lead.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between speed sensor coupler and ECU coupler. (blue–blue) (white–white) (black/blue–black/blue) 	
3	Gear for detecting vehicle speed has broken.		<ul style="list-style-type: none"> • Replace if defective. Refer to “TRANSMISSION” in chapter 4. 	
4	Defective speed sensor.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D07) • Replace if defective. Refer to “SIGNALING SYSTEM” in chapter 9. 	



Fault code No.	43	Symptom	Power supply to the injector and fuel pump is not normal.	
Diagnostic code No.		D09	Fuel system voltage	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Connections <ul style="list-style-type: none"> • Fuel injection system relay • Main wire harness-ECU coupler 		<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 	Starting the engine and operating it at idle.
2	Open or short circuit in the wire harness.		<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between fuel injection system relay coupler and ECU coupler. (blue/red–blue/red) (red/blue–red/blue) • Between fuel injection system relay coupler and starter relay coupler. (brown/black–brown/black) • Between fuel injection system relay coupler and left handlebar switch coupler. (red/black–red/black) 	
3	Malfunction or open circuit in fuel pump relay.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D09) • Replace if defective. • If there is no malfunction with the relay unit, replace the ECU. 	

Fault code No.	44	Symptom	Error is detected while reading or writing on EEPROM (CO adjustment value).	
Diagnostic code No.		D60	EEPROM improper cylinder indication	
Order	Item/components and probable cause		Check or maintenance job	Reinstatement method
1	Malfunction in ECU.		<ul style="list-style-type: none"> • Execute the diagnostic mode. (Code No.D60) 1. Check the faulty cylinder. • Replace ECU if defective. 	Turning the main switch to “ON”.



Fault code No.	46	Symptom	Power supply is not normal.	
Diagnostic code No.	—	—		
Order	Item/components and probable cause	Check or maintenance job		Reinstatement method
1	Connections <ul style="list-style-type: none"> • Main wire harness-ECU coupler 	<ul style="list-style-type: none"> • Check the coupler for any pins that may be pulled out. • Check the locking condition of the coupler. • If there is a malfunction, repair it and connect the coupler securely. 		Starting the engine and operating it at idle.
2	Faulty battery.	<ul style="list-style-type: none"> • Replace or charge the battery. Refer to “CHECKING AND CHARGING THE BATTERY” in chapter 3. 		
3	Malfunction in rectifier/regulator	<ul style="list-style-type: none"> • Replace if defective. Refer to “CHARGING SYSTEM” in chapter 9. 		
4	Open or short circuit in wire harness.	<ul style="list-style-type: none"> • Repair or replace if there is an open or short circuit. • Between battery lead and main switch coupler (red–red) • Between main switch coupler and ignition fuse (brown/blue–brown/blue) • Between ignition fuse and ECU coupler (brown–brown) 		

Fault code No.	50	Symptom	Faulty ECU memory. (When this malfunction is detected in the ECU, the fault code number might not appear on the meter.)	
Diagnostic code No.	—	—		
Order	Item/components and probable cause	Check or maintenance job		Reinstatement method
1	Malfunction in ECU.	Replace the ECU. NOTE: _____ Do not perform this procedure with the main switch turned to “ON”. _____		Turning the main switch to “ON”.

