



YFM7FGPW

SERVICE MANUAL

EBS00001

**YFM7FGPW
SERVICE MANUAL**

©2006 by Yamaha Motor Corporation, U.S.A.

First Edition, May 2006

All rights reserved.

**Any reproduction or unauthorized use
without the written permission of
Yamaha Motor Corporation, U.S.A.
is expressly prohibited.**

Printed in U.S.A.

LIT-11616-20-11

NOTICE

This manual was produced by the Yamaha Motor Company primarily for use by Yamaha dealers and their qualified mechanics. It is not possible to include all the knowledge of a mechanic in one manual, so it is assumed that anyone who uses this book to perform maintenance and repairs on Yamaha vehicle has a basic understanding of the mechanical ideas and the procedures of vehicle repair. Repairs attempted by anyone without this knowledge are likely to render the vehicle unsafe and unfit for use.

This model has been designed and manufactured to perform within certain specifications in regard to performance and emissions. Proper service with the correct tools is necessary to ensure that the vehicle will operate as designed. If there is any question about a service procedure, it is imperative that you contact a Yamaha dealer for any service information changes that apply to this model. This policy is intended to provide the customer with the most satisfaction from his vehicle and to conform to federal environmental quality objectives.

Yamaha Motor Company, Ltd. is continually striving to improve all its models. Modifications and significant changes in specifications or procedures will be forwarded to all authorized Yamaha dealers and will appear in future editions of this manual where applicable.

NOTE:

-
- This Service Manual contains information regarding periodic maintenance to the emission control system. Please read this material carefully.
 - Designs and specifications are subject to change without notice.
-

IMPORTANT INFORMATION

Particularly important information is distinguished in this manual by the following notations.



The Safety Alert Symbol means **ATTENTION! BECOME ALERT! YOUR SAFETY IS INVOLVED!**



Failure to follow **WARNING** instructions could result in severe injury or death to the vehicle operator, a bystander or a person checking or repairing the vehicle.



A **CAUTION** indicates special precautions that must be taken to avoid damage to the vehicle.

NOTE:

A **NOTE** provides key information to make procedures easier or clearer.

HOW TO USE THIS MANUAL

MANUAL ORGANIZATION

This manual consists of chapters for the main categories of subjects. (See “symbols”)

1st title ①: This is the title of the chapter with its symbol in the upper right corner of each page.

2nd title ②: This title indicates the section of the chapter and only appears on the first page of each section. It is located in the upper left corner of the page.

3rd title ③: This title indicates a sub-section that is followed by step-by-step procedures accompanied by corresponding illustrations.


EXPLODED DIAGRAMS

To help identify parts and clarify procedure steps, there are exploded diagrams at the start of each removal and disassembly section.

1. An easy-to-see exploded diagram ④ is provided for removal and disassembly jobs.
2. Numbers ⑤ are given in the order of the jobs in the exploded diagram. A number that is enclosed by a circle indicates a disassembly step.
3. An explanation of jobs and notes is presented in an easy-to-read way by the use of symbol marks ⑥. The meanings of the symbol marks are given on the next page.
4. A job instruction chart ⑦ accompanies the exploded diagram, providing the order of jobs, names of parts, notes in jobs, etc.
5. For jobs requiring more information, the step-by-step format supplements ⑧ are given in addition to the exploded diagram and the job instruction chart.

②
①

CLUTCH
ENG

④


⑤

⑥

⑦

Order	Job/Part	Qty	Remarks
Removing the clutch			
	Primary sheave/secondary sheave		Remove the parts in the order listed. Refer to "PRIMARY AND SECONDARY SHEAVES".
1	Clutch housing assembly	1	Refer to "REMOVING THE CLUTCH" and "INSTALLING THE CLUTCH".
2	Gasket	1	
3	Dowel pin	2	
4	One-way clutch bearing	1	
5	Nut	1	
6	Clutch carrier assembly	1	
			For installation, reverse the removal procedure.

③

REMOVING THE CLUTCH

1. Remove:

- clutch housing assembly
- gasket
- dowel pins

NOTE:
Working in crisscross pattern, loosen each bolt 1/4 of a turn. Remove them after all of them are loosened.

⑧

2. Straighten:

- punched portion of the nut ①

3. Remove:

























- nut ②

CAUTION:
The clutch carrier assembly nut has left-handed threads. To loosen the clutch carrier assembly nut turn it clockwise.

NOTE:
Use a clutch holding tool ② to hold the clutch carrier assembly.

Universal clutch holder
90890-04086, YM-91042

4 - 63
4 - 65

① GEN INFO 	② SPEC 	
③ CHK ADJ 	④ ENG 	
⑤ COOL 	⑥ FI 	
⑦ DRIV 	⑧ CHAS 	
⑨ ELEC 	⑩ TRBL SHTG ?	
⑪ 	⑫ 	
⑬ 	⑭ 	
⑮ 	⑯ 	
⑰ 	⑱ 	
⑲ 	⑳ 	㉑ 
㉒ 	㉓ 	㉔ 
㉕ 	㉖ New	

EBS00006

SYMBOLS

The following symbols are not relevant to every vehicle.

Symbols ① to ⑩ indicate the subject of each chapter.

- ① General information
- ② Specifications
- ③ Periodic checks and adjustments
- ④ Engine
- ⑤ Cooling system
- ⑥ Fuel injection system
- ⑦ Drive train
- ⑧ Chassis
- ⑨ Electrical
- ⑩ Troubleshooting

Symbols ⑪ to ⑱ indicate the following

- ⑪ Can be serviced with engine mounted
- ⑫ Filling fluid
- ⑬ Lubricant
- ⑭ Special tool
- ⑮ Torque
- ⑯ Wear limit, clearance
- ⑰ Engine speed
- ⑱ Electrical data (Ω , V, A)










Symbols ⑲ to ㉔ in the exploded diagrams indicate the types of lubricants and lubrication points.

- ⑲ Apply engine oil
- ⑳ Apply gear oil
- ㉑ Apply molybdenum disulfide oil
- ㉒ Apply wheel bearing grease
- ㉓ Apply lithium-soap-based grease
- ㉔ Apply molybdenum disulfide grease

Symbols ㉕ to ㉖ in the exploded diagrams indicate where to apply a locking agent ㉕ and when to install a new part ㉖.

- ㉕ Apply the locking agent (LOCTITE®)
- ㉖ Replace

TABLE OF CONTENTS

GENERAL INFORMATION	
	GEN INFO 1
SPECIFICATIONS	
	SPEC 2
PERIODIC CHECKS AND ADJUSTMENTS	
	CHK ADJ 3
ENGINE	
	ENG 4
COOLING SYSTEM	
	COOL 5
FUEL INJECTION SYSTEM	
	FI 6
DRIVE TRAIN	
	DRIV 7
CHASSIS	
	CHAS 8
ELECTRICAL	
	ELEC 9
TROUBLESHOOTING	?
	TRBL SHTG 10

CONTENTS

CHAPTER 1 GENERAL INFORMATION

VEHICLE IDENTIFICATION	1-1
VEHICLE IDENTIFICATION NUMBER	1-1
MODEL LABEL.....	1-1
FEATURES	1-2
OUTLINE OF THE FI SYSTEM.....	1-2
FI SYSTEM.....	1-3
OUTLINE OF THE EPS (ELECTRIC POWER STEERING) SYSTEM.....	1-4
EPS (ELECTRIC POWER STEERING) SYSTEM BLOCK DIAGRAM	1-5
INSTRUMENT FUNCTIONS	1-6
IMPORTANT INFORMATION	1-9
PREPARATION FOR REMOVAL AND DISASSEMBLY.....	1-9
REPLACEMENT PARTS.....	1-9
GASKETS, OIL SEALS AND O-RINGS	1-9
LOCK WASHERS/PLATES AND COTTER PINS	1-10
BEARINGS AND OIL SEALS	1-10
CIRCLIPS	1-10
CHECKING THE CONNECTIONS.....	1-11
SPECIAL TOOLS	1-12

CHAPTER 2 SPECIFICATIONS

GENERAL SPECIFICATIONS	2-1
ENGINE SPECIFICATIONS	2-5
CHASSIS SPECIFICATIONS	2-12
ELECTRICAL SPECIFICATIONS	2-14
TIGHTENING TORQUES	2-16
ENGINE TIGHTENING TORQUES.....	2-16
CHASSIS TIGHTENING TORQUES.....	2-19
HOW TO USE THE CONVERSION TABLE	2-22

GENERAL TIGHTENING TORQUE SPECIFICATIONS	2-22
LUBRICATION POINTS AND LUBRICANT TYPES	2-23
ENGINE.....	2-23
COOLANT FLOW DIAGRAMS	2-25
OIL FLOW DIAGRAMS	2-26
CABLE ROUTING	2-28

CHAPTER 3

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION	3-1
PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM	3-1
GENERAL MAINTENANCE AND LUBRICATION CHART	3-2
ENGINE SKID PLATES, SEAT, CARRIERS AND FENDERS	3-4
ENGINE SKID PLATES.....	3-4
SEAT AND SIDE PANELS	3-5
FRONT CARRIER AND FRONT GUARD	3-6
FRONT FENDERS AND FRONT GRILL.....	3-8
REAR CARRIER AND REAR FENDER	3-9
ELECTRICAL COMPONENTS TRAY	3-10
ELECTRICAL COMPONENTS TRAY 1/2	3-10
ELECTRICAL COMPONENTS TRAY 2/2	3-12
FOOTREST BOARDS	3-14
AIR FILTER CASE	3-15

ENGINE	3-16
ADJUSTING THE VALVE CLEARANCE	3-16
ADJUSTING THE ENGINE IDLING SPEED	3-19
ADJUSTING THE THROTTLE LEVER FREE PLAY	3-20
ADJUSTING THE SPEED LIMITER.....	3-22
CHECKING THE SPARK PLUG	3-23
CHECKING THE IGNITION TIMING.....	3-24
MEASURING THE COMPRESSION PRESSURE	3-25
CHECKING THE ENGINE OIL LEVEL.....	3-28
CHANGING THE ENGINE OIL	3-29
CLEANING THE AIR FILTER ELEMENT.....	3-31
CHECKING THE THROTTLE BODY JOINT	3-33
CHECKING THE FUEL HOSE	3-34
CHECKING THE BREATHER HOSES	3-34
CHECKING THE COOLANT LEVEL.....	3-35
CHANGING THE COOLANT.....	3-35
CHECKING THE COOLING SYSTEM	3-39
CHECKING THE COOLANT TEMPERATURE WARNING LIGHT	3-40
CHECKING THE V-BELT	3-41
CHECKING THE EXHAUST SYSTEM.....	3-42
CLEANING THE SPARK ARRESTER	3-43
CHASSIS	3-44
ADJUSTING THE FRONT BRAKE	3-44
ADJUSTING THE REAR BRAKE	3-44
CHECKING THE BRAKE FLUID LEVEL.....	3-46
CHECKING THE FRONT BRAKE PADS	3-47
CHECKING THE REAR BRAKE PADS	3-48
CHECKING THE REAR BRAKE HOSE PROTECTORS	3-48
CHECKING THE BRAKE HOSES.....	3-49
BLEEDING THE HYDRAULIC BRAKE SYSTEM	3-49
ADJUSTING THE SELECT LEVER CONTROL CABLE AND SHIFT ROD	3-51
CHECKING THE FINAL GEAR OIL LEVEL	3-53
CHANGING THE FINAL GEAR OIL.....	3-53
CHECKING THE DIFFERENTIAL GEAR OIL LEVEL.....	3-55
CHANGING THE DIFFERENTIAL GEAR OIL	3-55
CHECKING THE CONSTANT VELOCITY JOINT DUST BOOTS	3-56
CHECKING THE STEERING SYSTEM	3-57
ADJUSTING THE TOE-IN	3-59
CHECKING THE FRONT AND REAR SHOCK ABSORBERS	3-60
ADJUSTING THE FRONT SHOCK ABSORBERS	3-61
ADJUSTING THE REAR SHOCK ABSORBERS	3-62
CHECKING THE TIRES.....	3-62
CHECKING THE WHEELS	3-65
CHECKING AND LUBRICATING THE CABLES	3-65
LUBRICATING THE LEVERS AND PEDALS	3-66

ELECTRICAL SYSTEM	3-67
CHECKING AND CHARGING THE BATTERY	3-67
CHECKING THE FUSES	3-73
ADJUSTING THE HEADLIGHT BEAMS.....	3-76
REPLACING THE HEADLIGHT BULBS	3-76

CHAPTER 4

ENGINE

ENGINE REMOVAL	4-1
AIR DUCTS, MUFFLER AND EXHAUST PIPE	4-1
SELECT LEVER UNIT	4-3
LEADS, CABLES AND HOSES	4-4
ENGINE MOUNTING BOLTS	4-6
INSTALLING THE ENGINE.....	4-8
INSTALLING THE SELECT LEVER UNIT	4-9
CYLINDER HEAD	4-10
REMOVING THE CYLINDER HEAD.....	4-12
CHECKING THE CAMSHAFT SPROCKET	4-13
CHECKING THE TAPPET COVERS	4-13
CHECKING THE TIMING CHAIN TENSIONER.....	4-13
CHECKING THE CYLINDER HEAD	4-14
INSTALLING THE CYLINDER HEAD	4-15
ROCKER ARMS AND CAMSHAFT	4-18
REMOVING THE ROCKER ARMS AND CAMSHAFT.....	4-20
CHECKING THE CAMSHAFT.....	4-20
CHECKING THE DECOMPRESSION SYSTEM.....	4-21
CHECKING THE ROCKER ARMS AND ROCKER ARM SHAFTS	4-21
INSTALLING THE CAMSHAFT AND ROCKER ARMS	4-22
VALVES AND VALVE SPRINGS	4-25
REMOVING THE VALVES AND VALVE SPRINGS	4-26
CHECKING THE VALVES AND VALVE SPRINGS	4-27
INSTALLING THE VALVES AND VALVE SPRINGS	4-31
CYLINDER AND PISTON	4-34
REMOVING THE PISTON	4-35
CHECKING THE CYLINDER AND PISTON	4-35
CHECKING THE PISTON RINGS.....	4-37
CHECKING THE PISTON PIN	4-38
INSTALLING THE PISTON AND CYLINDER	4-39

AC MAGNETO	4-42
REMOVING THE AC MAGNETO ROTOR.....	4-45
CHECKING THE STATOR COIL AND CRANKSHAFT POSITION SENSOR	4-46
CHECKING THE STARTER CLUTCH	4-46
CHECKING THE TORQUE LIMITER.....	4-47
INSTALLING THE AC MAGNETO ROTOR	4-47
BALANCER GEARS AND OIL PUMP GEARS	4-49
REMOVING THE BALANCER DRIVEN GEAR AND OIL PUMP DRIVEN GEAR.....	4-51
CHECKING THE OIL PUMP DRIVE	4-51
CHECKING THE BALANCER DRIVE	4-51
INSTALLING THE BALANCER DRIVE GEAR, BALANCER DRIVEN GEAR, AND OIL PUMP DRIVEN GEAR.....	4-52
PRIMARY AND SECONDARY SHEAVES	4-53
PRIMARY SHEAVE.....	4-55
SECONDARY SHEAVE	4-56
REMOVING THE PRIMARY AND SECONDARY SHEAVES	4-57
DISASSEMBLING THE SECONDARY SHEAVE.....	4-57
CHECKING THE PRIMARY SHEAVE	4-58
CHECKING THE SECONDARY SHEAVE	4-58
ASSEMBLING THE PRIMARY SHEAVE	4-59
ASSEMBLING THE SECONDARY SHEAVE.....	4-60
INSTALLING THE PRIMARY AND SECONDARY SHEAVES.....	4-62
CLUTCH	4-63
REMOVING THE CLUTCH	4-65
CHECKING THE CLUTCH.....	4-66
INSTALLING THE CLUTCH.....	4-67
CRANKCASE	4-68
TIMING CHAIN AND OIL FILTER	4-68
CRANKCASE	4-70
CRANKCASE BEARINGS.....	4-71
SEPARATING THE CRANKCASE.....	4-72
CHECKING THE TIMING CHAIN AND GUIDE.....	4-72
CHECKING THE RELIEF VALVE	4-72
CHECKING THE BEARINGS.....	4-73
CHECKING THE CRANKCASE	4-73
ASSEMBLING THE CRANKCASE.....	4-73
INSTALLING THE SHIFT LEVER	4-74

CRANKSHAFT AND OIL PUMP	4-75
OIL PUMP	4-76
REMOVING THE CRANKSHAFT	4-77
CHECKING THE OIL PUMP	4-77
CHECKING THE OIL STRAINER	4-78
CHECKING THE CRANKSHAFT	4-78
ASSEMBLING THE OIL PUMP	4-79
INSTALLING THE CRANKSHAFT	4-79
TRANSMISSION	4-81
DRIVE AXLE	4-83
REMOVING THE TRANSMISSION	4-85
CHECKING THE SHIFT FORKS	4-85
CHECKING THE SHIFT DRUM	4-86
CHECKING THE TRANSMISSION	4-86
CHECKING THE SECONDARY SHAFT	4-87
CHECKING THE STOPPER LEVER AND STOPPER WHEEL	4-87
ASSEMBLING THE SHIFT FORK ASSEMBLY	4-87
INSTALLING THE TRANSMISSION	4-88
MIDDLE GEAR	4-89
MIDDLE DRIVE SHAFT	4-89
MIDDLE DRIVEN SHAFT	4-90
REMOVING THE MIDDLE DRIVE SHAFT	4-92
REMOVING THE MIDDLE DRIVEN SHAFT	4-93
CHECKING THE PINION GEARS	4-95
SELECTING MIDDLE DRIVE AND DRIVEN GEAR SHIMS	4-96
INSTALLING THE BEARING AND OIL SEALS	4-99
INSTALLING THE MIDDLE DRIVEN SHAFT	4-100
INSTALLING THE MIDDLE DRIVE SHAFT	4-102
MEASURING THE MIDDLE GEAR BACKLASH	4-102

CHAPTER 5

COOLING SYSTEM

RADIATOR	5-1
CHECKING THE RADIATOR	5-3
INSTALLING THE RADIATOR	5-4
THERMOSTAT	5-5
CHECKING THE THERMOSTAT	5-6
INSTALLING THE THERMOSTAT	5-6
WATER PUMP	5-7
DISASSEMBLING THE WATER PUMP	5-9
CHECKING THE WATER PUMP	5-9
ASSEMBLING THE WATER PUMP	5-10

CHAPTER 6

FUEL INJECTION SYSTEM

FUEL INJECTION SYSTEM	6-1
CIRCUIT DIAGRAM	6-3
ECU SELF-DIAGNOSTIC FUNCTION.....	6-5
SELF-DIAGNOSTIC FUNCTION TABLE	6-6
TROUBLESHOOTING CHART	6-7
DIAGNOSTIC MODE	6-8
TROUBLESHOOTING DETAILS	6-12
CHECKING THE INTAKE AIR PRESSURE SENSOR	6-26
CHECKING THE INTAKE AIR TEMPERATURE SENSOR	6-26
FUEL TANK	6-28
REMOVING THE FUEL TANK	6-30
REMOVING THE FUEL PUMP	6-30
CHECKING THE FUEL PUMP BODY.....	6-31
CHECKING THE ROLLOVER VALVE	6-31
INSTALLING THE FUEL PUMP	6-31
INSTALLING THE FUEL HOSE	6-32
THROTTLE BODY	6-33
REMOVING THE THROTTLE BODY ASSEMBLY	6-36
CHECKING THE FUEL INJECTOR	6-36
CHECKING THE THROTTLE BODY	6-36
INSTALLING THE THROTTLE BODY ASSEMBLY	6-37
CHECKING THE FUEL PUMP AND PRESSURE REGULATOR OPERATION	6-38
CHECKING AND ADJUSTING THE THROTTLE POSITION SENSOR	6-39

CHAPTER 7

DRIVE TRAIN

TROUBLESHOOTING	7-1
CHECKING NOISES	7-1
TROUBLESHOOTING CHART	7-3

FRONT CONSTANT VELOCITY JOINTS AND DIFFERENTIAL GEAR.....	7-4
REMOVING THE DIFFERENTIAL GEAR ASSEMBLY.....	7-10
CHECKING THE FRONT CONSTANT VELOCITY JOINTS.....	7-10
CHECKING THE DIFFERENTIAL GEARS	7-11
CHECKING THE DIFFERENTIAL GEAR MOTOR	7-11
ASSEMBLING THE FRONT CONSTANT VELOCITY JOINTS	7-12
ASSEMBLING THE DIFFERENTIAL GEARS.....	7-13
MEASURING THE DIFFERENTIAL GEAR LASH	7-14
ADJUSTING THE DIFFERENTIAL GEAR LASH.....	7-15
CHECKING THE DIFFERENTIAL GEAR OPERATION	7-16

REAR CONSTANT VELOCITY JOINTS AND FINAL DRIVE GEAR	7-17
ASSEMBLING THE REAR CONSTANT VELOCITY JOINTS.....	7-24
DISASSEMBLING THE FINAL DRIVE PINION GEAR ASSEMBLY.....	7-25
POSITIONING THE FINAL DRIVE PINION GEAR AND RING GEAR ...	7-25
ADJUSTING THE FINAL DRIVE PINION GEAR BACKLASH	7-25
ADJUSTING THE FINAL DRIVEN PINION GEAR BACKLASH	7-27
MEASURING THE FINAL DRIVEN PINION GEAR THRUST WASHER CLEARANCE	7-29
MEASURING THE WHEEL GEAR THRUST CLEARANCE	7-30
CHECKING THE REAR DRIVE SHAFT.....	7-31
CHECKING THE FINAL DRIVE ASSEMBLY	7-31
MEASUREMENT THE FINAL GEAR LASH.....	7-32
ADJUSTING THE FINAL GEAR LASH	7-33
ASSEMBLING THE FINAL DRIVE PINION GEAR ASSEMBLY.....	7-34
ASSEMBLING THE FINAL GEAR CASE	7-35

CHAPTER 8

CHASSIS

FRONT AND REAR WHEELS	8-1
FRONT WHEELS	8-1
REAR WHEELS	8-3
CHECKING THE WHEELS	8-5
CHECKING THE WHEEL HUBS.....	8-5
CHECKING THE BRAKE DISCS	8-6
INSTALLING THE BRAKE DISCS	8-6
INSTALLING THE WHEEL HUBS.....	8-6
INSTALLING THE WHEELS	8-7

FRONT AND REAR BRAKES	8-8
FRONT BRAKE PADS	8-8
REAR BRAKE PADS.....	8-9
REPLACING THE FRONT AND REAR BRAKE PADS.....	8-10
FRONT BRAKE MASTER CYLINDER.....	8-12
REAR BRAKE MASTER CYLINDER	8-15
CHECKING THE MASTER CYLINDERS.....	8-18
ASSEMBLING THE FRONT AND REAR BRAKE MASTER CYLINDERS	8-18
INSTALLING THE FRONT BRAKE MASTER CYLINDER.....	8-19
INSTALLING THE REAR BRAKE MASTER CYLINDER	8-21
FRONT BRAKE CALIPERS	8-23
REAR BRAKE CALIPERS.....	8-25
DISASSEMBLING THE FRONT AND REAR BRAKE CALIPERS	8-27
CHECKING THE FRONT AND REAR BRAKE CALIPERS	8-27
ASSEMBLING THE FRONT AND REAR BRAKE CALIPERS	8-28
INSTALLING THE FRONT AND REAR BRAKE CALIPERS	8-29
STEERING SYSTEM	8-31
HANDLEBAR.....	8-31
REMOVING THE HANDLEBAR GRIPS.....	8-33
CHECKING THE HANDLEBAR	8-33
INSTALLING THE HANDLEBAR	8-33
INSTALLING THE HANDLEBAR GRIPS	8-34
INSTALLING THE REAR BRAKE MASTER CYLINDER	8-34
INSTALLING THE FRONT BRAKE MASTER CYLINDER.....	8-35
INSTALLING THE THROTTLE LEVER ASSEMBLY	8-35
STEERING STEM	8-36
CHECKING THE STEERING STEM	8-38
INSTALLING THE STEERING STEM	8-38
INSTALLING THE PITMAN ARM.....	8-40
TIE-RODS AND STEERING KNUCKLES	8-41
REMOVING THE STEERING KNUCKLES	8-43
CHECKING THE TIE-RODS	8-43
CHECKING THE STEERING KNUCKLES.....	8-43
INSTALLING THE TIE-RODS	8-46
FRONT ARMS AND FRONT SHOCK ABSORBER ASSEMBLIES	8-47
REMOVING THE FRONT ARMS	8-49
CHECKING THE FRONT ARMS.....	8-49
CHECKING THE FRONT SHOCK ABSORBERS.....	8-51
INSTALLING THE FRONT ARMS AND FRONT SHOCK ABSORBERS	8-51
REAR KNUCKLES AND STABILIZER	8-52
CHECKING THE REAR KNUCKLES	8-54
CHECKING THE STABILIZER.....	8-54

REAR ARMS AND REAR SHOCK ABSORBER ASSEMBLIES	8-55
CHECKING THE REAR ARMS	8-57
CHECKING THE REAR SHOCK ABSORBER ASSEMBLIES	8-57
INSTALLING THE REAR ARMS AND REAR SHOCK ABSORBER ASSEMBLIES	8-58

CHAPTER 9 ELECTRICAL

ELECTRICAL COMPONENTS	9-1
CHECKING SWITCH CONTINUITY	9-4
CHECKING THE SWITCHES	9-5
CHECKING THE BULBS AND BULB SOCKETS	9-7
TYPES OF BULBS	9-7
CHECKING THE CONDITION OF THE BULBS	9-8
CHECKING THE CONDITION OF THE BULB SOCKETS	9-9
IGNITION SYSTEM	9-10
CIRCUIT DIAGRAM	9-10
TROUBLESHOOTING	9-11
ELECTRIC STARTING SYSTEM	9-16
CIRCUIT DIAGRAM	9-16
STARTING CIRCUIT OPERATION	9-17
TROUBLESHOOTING	9-18
STARTER MOTOR	9-22
CHECKING THE STARTER MOTOR	9-24
ASSEMBLING THE STARTER MOTOR	9-26
CHARGING SYSTEM	9-27
CIRCUIT DIAGRAM	9-27
TROUBLESHOOTING	9-28
LIGHTING SYSTEM	9-30
CIRCUIT DIAGRAM	9-30
TROUBLESHOOTING	9-31
CHECKING THE LIGHTING SYSTEM	9-32
SIGNALING SYSTEM	9-34
CIRCUIT DIAGRAM	9-34
TROUBLESHOOTING	9-36
CHECKING THE SIGNALING SYSTEM	9-37


COOLING SYSTEM	9-45
CIRCUIT DIAGRAM	9-45
TROUBLESHOOTING	9-46
FUEL PUMP SYSTEM	9-50
CIRCUIT DIAGRAM	9-50
TROUBLESHOOTING	9-51
2WD/4WD SELECTING SYSTEM	9-53
CIRCUIT DIAGRAM	9-53
TROUBLESHOOTING	9-54
EPS (ELECTRIC POWER STEERING) SYSTEM	9-58
CIRCUIT DIAGRAM	9-58
EPS CONTROL UNIT'S SELF-DIAGNOSTIC FUNCTION	9-59
EPS WARNING LIGHT DURING NORMAL OPERATION.....	9-60
DIAGNOSTIC MODE	9-61
SELF-DIAGNOSTIC FUNCTION TABLE (EPS SYSTEM).....	9-64
TROUBLESHOOTING DETAILS (EPS SYSTEM)	9-65
CHECKING THE EPS MOTOR.....	9-69
CHECKING THE EPS TORQUE SENSOR.....	9-69

CHAPTER 10

TROUBLESHOOTING

STARTING FAILURE/HARD STARTING	10-1
FUEL SYSTEM.....	10-1
ELECTRICAL SYSTEM.....	10-1
COMPRESSION SYSTEM.....	10-2
POOR IDLE SPEED PERFORMANCE	10-2
POOR IDLE SPEED PERFORMANCE	10-2
POOR MEDIUM AND HIGH-SPEED PERFORMANCE	10-2
POOR MEDIUM AND HIGH-SPEED PERFORMANCE	10-2
FAULTY DRIVE TRAIN	10-3
FAULTY GEAR SHIFTING	10-4
HARD SHIFTING.....	10-4
SHIFT LEVER DOES NOT MOVE	10-4
JUMPS OUT OF GEAR.....	10-4

FAULTY CLUTCH PERFORMANCE	10-4
ENGINE OPERATES BUT VEHICLE WILL NOT MOVE	10-4
CLUTCH SLIPPING	10-4
POOR STARTING PERFORMANCE	10-4
POOR SPEED PERFORMANCE	10-5
OVERHEATING	10-5
OVERHEATING	10-5
OVERCOOLING	10-5
COOLING SYSTEM	10-5
FAULTY BRAKE	10-5
POOR BRAKING EFFECT	10-5
SHOCK ABSORBER MALFUNCTION	10-6
MALFUNCTION	10-6
UNSTABLE HANDLING	10-6
UNSTABLE HANDLING	10-6
LIGHTING SYSTEM	10-6
HEADLIGHT DOES NOT COME ON	10-6
BULB BURNT OUT	10-6




EBS00009

GENERAL INFORMATION
VEHICLE IDENTIFICATION

EBS00010

VEHICLE IDENTIFICATION NUMBER

The vehicle identification number ① is stamped into the front left side of the frame.



EBS00011

MODEL LABEL

The model label ① is affixed at the location in the illustration. This information will be needed to order spare parts.

EAS20170

FEATURES


OUTLINE OF THE FI SYSTEM

The main function of a fuel supply system is to provide fuel to the combustion chamber at the optimum air-fuel ratio in accordance with the engine operating conditions and the atmospheric temperature. In the conventional carburetor system, the air-fuel ratio of the mixture that is supplied to the combustion chamber is created by the volume of the intake air and the fuel that is metered by the jet used in the respective carburetor.

Despite the same volume of intake air, the fuel volume requirement varies with the engine operating conditions, such as acceleration, deceleration, or operating under a heavy load. Carburetors that meter the fuel through the use of jets have been provided with various auxiliary devices, so that an optimum air-fuel ratio can be achieved to accommodate the constant changes in the operating conditions of the engine.

As the requirements for the engine to deliver more performance and cleaner exhaust gases increase, it becomes necessary to control the air-fuel ratio in a more precise and finely tuned manner. To accommodate this need, this model has adopted an electronically controlled fuel injection (FI) system, in place of the conventional carburetor system. This system can achieve an optimum air-fuel ratio required by the engine at all times by using a microprocessor that regulates the fuel injection volume according to the engine operating conditions detected by various sensors.

The adoption of the FI system has resulted in a highly precise fuel supply, improved engine response, better fuel economy, and reduced exhaust emissions.



- ① ECU (engine control unit)
- ② Lean angle sensor
- ③ Fuel injection system relay
- ④ Engine trouble warning light
- ⑤ Intake air pressure sensor
- ⑥ TPS (throttle position sensor)
- ⑦ Intake air temperature sensor
- ⑧ Fuel injector


- ⑨ Fuel pump
- ⑩ Speed sensor
- ⑪ Crankshaft position sensor
- ⑫ Coolant temperature sensor
- ⑬ Spark plug
- ⑭ Ignition coil

FI SYSTEM

The fuel pump delivers fuel to the fuel injector via the fuel filter. The pressure regulator maintains the fuel pressure that is applied to the fuel injector at only 324 kPa (3.24 kg/cm², 46.1 psi). Accordingly, when the energizing signal from the ECU energizes the fuel injector, the fuel passage opens, causing the fuel to be injected into the intake manifold only during the time the passage remains open. Therefore, the longer the length of time the fuel injector is energized (injection duration), the greater the volume of fuel that is supplied. Conversely, the shorter the length of time the fuel injector is energized (injection duration), the lesser the volume of fuel that is supplied.


The injection duration and the injection timing are controlled by the ECU. Signals that are input from the throttle position sensor, crankshaft position sensor, intake air pressure sensor, intake air temperature sensor, coolant temperature sensor, lean angle sensor and speed sensor enable the ECU to determine the injection duration. The injection timing is determined through the signals from the crankshaft position sensor. As a result, the volume of fuel that is required by the engine can be supplied at all times in accordance with the driving conditions.

Illustration is for reference only.




- ① Fuel pump
 - ② Fuel injector
 - ③ Ignition coil
 - ④ ECU (engine control unit)
 - ⑤ Speed sensor
 - ⑥ Lean angle sensor
 - ⑦ Coolant temperature sensor
 - ⑧ Crankshaft position sensor
 - ⑨ Intake air pressure sensor
 - ⑩ Throttle body
 - ⑪ Throttle position sensor
 - ⑫ Intake air temperature sensor
 - ⑬ Air filter case
- A Fuel system
B Air system
C Control system


OUTLINE OF THE EPS (ELECTRIC POWER STEERING) SYSTEM



CAUTION: _____
 To prevent accidental damage to the EPS unit, it must not be disassembled.

EPS (ELECTRIC POWER STEERING) SYSTEM BLOCK DIAGRAM





INSTRUMENT FUNCTIONS

EBU27291

Multifunction display

- ① "CLOCK" button
- ② "RESET" button
- ③ "SELECT" button
- ④ Speedometer
- ⑤ Fuel meter
- ⑥ Clock/Hour meter
- ⑦ Odometer/Tripmeter A/Tripmeter B

The multifunction display is equipped with the following:

- a speedometer (which shows the riding speed)
- an odometer (which shows the total distance traveled)
- two tripmeters (which show the distance traveled since they were last set to zero)
- a clock
- an hour meter (which shows the total time the key has been turned to "ON")
- a fuel meter
- a self-diagnosis device

Odometer and tripmeter modes

Pushing the "SELECT" button switches the display between the odometer mode "ODO" and the tripmeter modes "A" and "B" in the following order:

ODO → TRIP A → TRIP B → ODO

To reset a tripmeter, select it by pushing the "SELECT" button, and then push the "RESET" button for at least three seconds. The tripmeters can be used to estimate the distance that can be traveled with a full tank of fuel. This information will enable you to plan future fuel stops.

NOTE: _____

Holding in the "SELECT" button and then turning the key to "ON" switches the display between "mph" and "km/h".


Clock mode

Pushing the “CLOCK” button switches the display between the clock mode “CLOCK” and the hour meter mode “HOUR” in the following order:

CLOCK → HOUR → CLOCK

To set the clock

1. Set the display to the clock mode.
2. Push the “SELECT” button and “RESET” button together for at least three seconds.
3. When the hour digits start flashing, push the “RESET” button to set the hours.
4. Push the “SELECT” button, and the minute digits will start flashing.
5. Push the “RESET” button to set the minutes.
6. Push the “SELECT” button and then release it to start the clock.

**Fuel meter**


The fuel meter indicates the amount of fuel in the fuel tank. The display segments of the fuel meter disappear from “F” (full) towards “E” (empty) as the fuel level decreases. When the “E” segment disappears and the fuel level warning indicator flashes, refuel as soon as possible.

NOTE:

This fuel meter is equipped with a self-diagnosis system. If the electrical circuit is defective, all the display segments and fuel level warning indicator will start flashing. If this occurs, check the electrical circuit.

Refer to “SIGNALING SYSTEM” in chapter 9.

- ① Fuel level warning indicator
- ② Fuel meter
- ③ “E” segment



Self-diagnosis device

This model is equipped with a self-diagnosis device for various electrical circuits.

If any of those circuits are defective, the multifunction display will indicate a two-digit error code. If the multifunction display indicates such an error code, note the code number, and check the vehicle.

ECB00810

CAUTION:

If the multifunction display indicates an error code, the vehicle should be checked as soon as possible in order to avoid engine damage.

① Error code display

EBS00013

**IMPORTANT INFORMATION
PREPARATION FOR REMOVAL AND
DISASSEMBLY**

1. Before removal and disassembly remove all dirt, mud, dust and foreign material.
2. Use only the proper tools and cleaning equipment.
Refer to "SPECIAL TOOLS".
3. When disassembling always keep mated parts together. This includes gears, cylinders, pistons and other parts that have been "mated" through normal wear. Mated parts must always be reused or replaced as an assembly.
4. During disassembly, clean all of the parts and place them in trays in the order of disassembly. This will speed up assembly and allow for the correct installation of all parts.
5. Keep all parts away from any source of fire.

EBS00014


REPLACEMENT PARTS

1. Use only genuine Yamaha parts for all replacements. Use oil and grease recommended by Yamaha for all lubrication jobs. Other brands may be similar in function and appearance, but inferior in quality.

EBS00015

GASKETS, OIL SEALS AND O-RINGS


1. When overhauling the engine, replace all gaskets, seals and O-rings. All gasket surfaces, oil seal lips and O-rings must be cleaned.
2. During reassembly properly oil all mating parts and bearings, and lubricate the oil seal lips with grease.



EBS00016

LOCK WASHERS/PLATES AND COTTER PINS

After removal, replace all lock washers/plates ① and cotter pins. After the bolt or nut has been tightened to specification, bend the lock tabs along a flat of the bolt or nut.



EBS00017


BEARINGS AND OIL SEALS

Install bearings and oil seals so that the manufacturer's marks or numbers are visible. When installing oil seals, lubricate the oil seal lips with a light coat of lithium-soap-based grease. Oil bearings liberally when installing, if appropriate.


① Oil seal

CAUTION:

Do not spin the bearing with compressed air because this will damage the bearing surfaces.



① Bearing





EBS00018

CIRCLIPS

Before reassembly, check all circlips carefully and replace damaged or distorted circlips. Always replace piston pin clips after one use. When installing a circlip ①, make sure the sharp-edged corner ② is positioned opposite the thrust ③ that the circlip receives.

④ Shaft



EBS00019

CHECKING THE CONNECTIONS

Check the leads, couplers, and connectors for stains, rust, moisture, etc.

1. Disconnect:

- lead
- coupler
- connector

2. Check:

- lead
- coupler
- connector

Moisture → Dry with an air blower.

Rust/stains → Connect and disconnect several times.

3. Check:

- all connections

Loose connection → Connect properly.

NOTE:



If the pin ① on the terminal is flattened, bend it up.

4. Connect:

- lead
- coupler
- connector


NOTE:

Make sure all connections are tight.



5. Check:

- continuity (with the pocket tester)

	<p>Pocket tester 90890-03112 Analog pocket tester YU-03112-C</p>
---	---

NOTE:

- If there is no continuity, clean the terminals.
- When checking the wire harness, perform steps (1) to (3).
- As a quick remedy, use a contact revitalizer available at most part stores.

EBS00021

SPECIAL TOOLS

The following special tools are necessary for complete and accurate tune-up and assembly. Use only the appropriate special tools; this will help prevent damage caused by the use of inappropriate tools or improvised techniques. Special tools may differ by shape and part number from country to country. In such a case, two types are provided.








When placing an order, refer to the list provided below to avoid any mistakes.

For US and CDN









P/N. YM-, YU-, YS-, YK-, ACC-

Except for US and CDN










P/N. 90890-

Tool No.	Tool name/How to use	Illustration
90890-01083 YU-01083-1	Slide hammer bolt Slide hammer bolt 6 mm This tool is used to remove the rocker arm shaft.	
90890-01084 YU-01083-3	Weight This tool is used to remove the rocker arm shaft.	90890-01084 
		YU-01083-3 
90890-01135 YU-01135-B	Crankcase separating tool Crankcase separator This tool is used to separate the crankcase.	90890-01135 
		YU-01135-B 
90890-01229 YM-01229	Coupling gear/middle shaft tool Gear holder This tool is needed when removing or installing the coupling gear nut.	
90890-01243 YM-01253-1	Valve spring compressor attachment Valve spring compressor adapter (26 mm) This tool is needed to remove and install the valve assemblies.	












Tool No.	Tool name/How to use	Illustration
90890-01274 YU-90058 YU-90059	Crankshaft installer pot Installing pot Pot installer	90890-01274 
	This tool is used to install the crankshaft.	YU-90058/YU-90059 
90890-01275 YU-90060	Crankshaft installer bolt Bolt This tool is used to install the crankshaft.	 M14xP1.5
90890-01304 YU-01304	Piston pin puller set Piston pin puller This tool is used to remove the piston pin.	90890-01304  M6xP1.0
		YU-01304 
90890-01309 YU-90059	Spacer Pot spacer This tool is used to install the crankshaft.	 ø35
90890-01311 YM-08035-A	Tappet adjusting tool Valve adjuster 3 mm & 4 mm This tool is necessary for adjusting the valve clearance.	90890-01311  3mm
		YM-08035-A 












Tool No.	Tool name/How to use	Illustration
90890-01325 YU-24460-01	Radiator cap tester Radiator pressure tester	90890-01325 
	This tool is used to check the cooling system.	YU-24460-01 
90890-01348 YM-01348	Locknut wrench	90890-01348 
	This tool is needed when removing or installing the secondary sheave spring.	YM-01348 
90890-01352 YU-33984	Radiator cap tester adapter Radiator pressure tester adapter	90890-01352 
	This tool is used to check the cooling system.	YU-33984 
90890-01362 YU-33270-B	Flywheel puller Heavy duty puller This tool is used to remove the AC magneto rotor.	
90890-01426 YU-38411	Oil filter wrench This tool is needed to loosen or tighten the oil filter cartridge.	
90890-01430 YM-38404	Ring nut wrench This tool is needed to removing and installing the middle driven shaft bearing retainer.	












Tool No.	Tool name/How to use	Illustration
90890-01474 YM-01474	<p>Ball joint remover</p> <p>These tools are used to removing or installing the ball joints.</p>	
90890-01475 YM-01475	<p>Gear lash measurement tool Middle drive gear lash tool</p> <p>This tool is used to measure the gear lash.</p>	
90890-01480 YM-01480	<p>Ball joint remover attachment set Ball joint adapter set</p> <p>These tools are used to removing or installing the ball joints.</p>	
90890-01511	<p>Final gear backlash band</p> <p>This tool is needed when measuring the final gear backlash.</p>	
90890-01514	<p>Ball joint remover short shaft set</p> <p>These tools are used to removing or installing the ball joints.</p>	
90890-01701 YS-01880-A	<p>Sheave holder Primary clutch holder</p> <p>This tool is needed to hold the primary sheave when removing or installing the sheave nuts.</p>	
90890-03079 YM-34483	<p>Thickness gauge Narrow gauge set</p> <p>This tool is used to measure the valve clearance.</p>	
90890-03081 YU-33223	<p>Compression gauge Engine compression tester</p> <p>This tool is needed to measure engine compression.</p>	
90890-03112 YU-03112-C	<p>Pocket tester Analog pocket tester</p> <p>This instrument is needed for checking the electrical systems.</p>	










Tool No.	Tool name/How to use	Illustration
90890-03141 YU-03141	Timing light Inductive clamp timing light This tool is necessary for checking ignition timing.	
90890-03153 YU-03153	Pressure gauge This tool is used to measure fuel pressure.	
90890-03170 YM-03170	Belt tension gauge Rear drive belt tension gauge This tool is used to measure the steering tension.	
90890-03174 YU-A1927	Digital circuit tester Model 88 Multimeter with tachometer This tool is used to check the electrical systems.	
90890-03176 YM-03176	Fuel pressure adapter This tool is used to measure fuel pressure.	
90890-04019 YM-04019	Valve spring compressor This tool is used to remove or install the valve assemblies.	
90890-04058 YM-04058	Middle driven shaft bearing driver Bearing driver 40 mm This tool is used to install the water pump seal.	
90890-04064 YM-04064-A	Valve guide remover (ø6) Valve guide remover (6.0 mm) This tool is needed to remove and install the valve guides.	
90890-04065 YM-04065-A	Valve guide installer (ø6) Valve guide installer (6.0 mm) This tool is needed to install the valve guides.	



Tool No.	Tool name/How to use	Illustration
90890-04066 YM-04066	Valve guide reamer (ø6) Valve guide reamer (6.0 mm) This tool is needed to rebore the new valve guides.	
90890-04081 YM-91044	Spacer (crankshaft installer) Pot spacer This tool is used to install the crankshaft.	90890-04081  ø84
		YM-91044 
90890-04082	Extension This tool is used to measure engine compression.	 73
90890-04086 YM-91042	Universal clutch holder This tool is needed to hold the clutch carrier when removing or installing the carrier nut.	90890-04086  M8×P1.25 30 119 156
		YM-91042 
90890-04128 YM-04128	Bearing retainer wrench Middle gear bearing retainer This tool is needed when removing or installing the bearing retainers.	 50×23×2.0
90890-04130 YM-04059	Adapter (M16) Adapter #13 This tool is used to install the crankshaft.	 M14×P1.5 M16×P1.5
90890-04132 YM-33221-A	Mechanical seal installer Water pump seal installer This tool is used to install the water pump seal.	 ø33 ø27.5 ø14




Tool No.	Tool name/How to use	Illustration
90890-04134 YM-04134	Sheave spring compressor	90890-04134 
	This tool is needed when removing or installing the secondary sheave spring.	YM-04134 
90890-04135 YM-04135	Sheave fixed block Sheave fixed bracket	90890-04135 
	This tool is needed when removing or installing the secondary sheave spring.	YM-04135 
90890-06754 YM-34487	Ignition checker Opama pet-4000 spark checker This instrument is necessary for checking the ignition system components.	
90890-06760 YU-39951-B	Digital tachometer This tool is needed for checking engine rpm.	
90890-85505	Yamaha bond No. 1215 (Three bond No.1215®) This bond is used on crankcase mating surfaces, etc.	



EBS01001

SPECIFICATIONS

GENERAL SPECIFICATIONS

Item	Standard
Model code	3B41 3B45 3B48
Dimensions Overall length Overall width Overall height Seat height Wheelbase Minimum ground clearance Minimum turning radius	2,065 mm (81.3 in) 1,180 mm (46.5 in) 1,240 mm (48.8 in) 905 mm (35.6 in) 1,250 mm (49.2 in) 275 mm (10.8 in) 3,200 mm (126.0 in)
Basic weight With oil and fuel	294.0 kg (648 lb)
Engine Engine type Cylinder arrangement Displacement Bore × stroke Compression ratio Standard compression pressure (at sea level) Starting system	Liquid-cooled 4-stroke, SOHC Forward-inclined single cylinder 686.0 cm ³ (41.86 cu. in) 102.0 × 84.0 mm (4.02 × 3.31 in) 9.20 : 1 450 kPa (4.50 kg/cm ² , 64.0 psi) Electric starter
Lubrication system	Wet sump
Oil type or grade Engine oil  Final gear oil Differential gear oil	API service SE, SF, SG type or higher JASO standard MA SAE 80 API GL-4 Hypoid gear oil SAE 80 API GL-4 Hypoid gear oil



Item	Standard
Oil quantity	
Engine oil	
Periodic oil change	2.00 L (1.76 Imp qt, 2.11 US qt)
With oil filter replacement	2.10 L (1.85 Imp qt, 2.22 US qt)
Total amount	2.40 L (2.11 Imp qt, 2.54 US qt)
Final gear oil	
Periodic oil change	0.20 L (0.18 Imp qt, 0.21 US qt)
Total amount	0.25 L (0.22 Imp qt, 0.26 US qt)
Differential gear case oil	
Periodic oil change	0.215 L (0.19 Imp qt, 0.23 US qt)
Total amount	0.23 L (0.20 Imp qt, 0.24 US qt)
Radiator capacity (including all routes)	1.99 L (1.75 Imp qt, 2.10 US qt)
Air filter	Wet type element
Fuel	
Type	Unleaded gasoline only
Fuel tank capacity	20.0 L (4.40 Imp gal, 5.28 US gal)
Fuel reserve amount	4.5 L (0.99 Imp gal, 1.19 US gal)
Fuel injector	
Type/quantity	297500-1010/1
Manufacturer	DENSO
Spark plug	
Type/manufacturer	CR8E/NGK
Spark plug gap	0.7 ~ 0.8 mm (0.028 ~ 0.031 in)
Clutch type	Wet, centrifugal automatic
Transmission	
Primary reduction system	V-belt
Secondary reduction system	Shaft drive
Secondary reduction ratio	41/21 × 24/18 × 33/9 (9.544)
Transmission type	V-belt automatic
Operation	Left hand operation
Single speed automatic	2.380 ~ 0.700 : 1
Sub transmission ratio	low high
low	31/16 (1.938)
high	29/25 (1.160)
Reverse gear	23/14 × 28/23 (2.000)
Chassis	
Frame type	Steel tube frame
Caster angle	5.0°
Camber angle	0°
Kingpin angle	11.0°
Kingpin offset	0 mm (0 in)
Trail	26.0 mm (1.02 in)
Tread front (STD)	940.0 mm (37.01 in)
Tread rear (STD)	915.0 mm (37.01 in)
Toe-in (with tires touching the ground)	0 ~ 10.0 mm (0 ~ 0.39 in)



Item	Standard
Tire Type front rear Size front rear Manufacturer/model front rear	Tubeless Tubeless AT25 × 8-12 AT25 × 10-12 DUNLOP/KT421 DUNLOP/KT425
Tire pressure (cold tire) Maximum load* Off-road riding front rear *Load is total weight of cargo, rider, accessories, and tongue	220.0 kg (485 lb) 32 ~ 38 kPa (0.32 ~ 0.38 kg/cm ² , 4.6 ~ 5.5 psi) 27 ~ 33 kPa (0.27 ~ 0.33 kg/cm ² , 3.9 ~ 4.8 psi)
Brake Front brake type operation Rear brake type operation	Dual disc brake Right hand operation Dual disc brake Left hand and right foot operation
Suspension Front suspension Rear suspension	Double wishbone Double wishbone
Shock absorber Front shock absorber Rear shock absorber	Coil spring/oil damper Coil spring/oil damper
Wheel travel Front wheel travel Rear wheel travel	180 mm (7.1 in) 230 mm (9.1 in)
Electrical system Ignition system Generator system Battery type Battery capacity	Transistorized coil ignition (digital) AC magneto YTX20L-BS 12 V 18.0 Ah
Bulb type	Halogen bulb







Item	Standard
Bulb voltage/wattage × quantity	
Headlight	12 V 35.0 W/35.0 W × 2
Tail/brake light	12 V 21.0/5.0 W × 1
Indicator light	
Neutral indicator light	LED
Reverse indicator light	LED
Coolant temperature warning light	LED
Engine trouble warning light	LED
EPS warning light	LED
Park indicator light	LED
On-command four-wheel drive/differential gear lock indicator	LCD
High-range indicator light	LED
Low-range indicator light	LED
Differential gear lock indicator light	LED







EBS01002



ENGINE SPECIFICATIONS

Item	Standard	Limit
<p>Cylinder head Maximum warpage *</p> 	<p>----</p>	<p>0.03 mm (0.0012 in)</p>
<p>Cylinder Bore</p> <p>Measuring point *</p>  <p>Maximum taper</p> <p>Out of round</p>	<p>102.000 ~ 102.010 mm (4.0157 ~ 4.0161 in)</p> <p>50.0 mm (1.97 in)</p>	<p>102.080 mm (4.0189 in)</p> <p>----</p> <p>0.05 mm (0.002 in)</p> <p>0.05 mm (0.002 in)</p>
<p>Camshaft Drive system</p> <p>Camshaft lobe dimensions</p>  <p>Intake measurement "A"</p> <p>"B"</p> <p>Exhaust measurement "A"</p> <p>"B"</p> <p>Maximum camshaft runout</p> 	<p>Chain drive (left)</p> <p>43.488 ~ 43.588 mm (1.7121 ~ 1.7161 in)</p> <p>36.959 ~ 37.059 mm (1.4551 ~ 1.4590 in)</p> <p>43.129 ~ 43.229 mm (1.6980 ~ 1.7019 in)</p> <p>37.007 ~ 37.107 mm (1.4570 ~ 1.4609 in)</p> <p>----</p>	<p>----</p> <p>43.388 mm (1.7082 in)</p> <p>36.859 mm (1.4511 in)</p> <p>43.029 mm (1.6941 in)</p> <p>36.907 mm (1.4530 in)</p> <p>0.015 mm (0.0006 in)</p>






Item	Standard	Limit
Timing chain		
Model/number of links	98XRH2010/126	----
Tensioning system	Automatic	----
Rocker arm/rocker arm shaft		
Rocker arm inside diameter	12.000 ~ 12.018 mm (0.4724 ~ 0.4731 in)	----
Shaft outside diameter	11.981 ~ 11.991 mm (0.4717 ~ 0.4721 in)	----
Arm-to-shaft clearance	0.009 ~ 0.037 mm (0.0004 ~ 0.0015 in)	----
Rocker-arm-to-rocker-arm-shaft clearance	0.009 ~ 0.037 mm (0.0004 ~ 0.0015 in)	----
Valve, valve seat, valve guide		
Valve clearance—intake (cold)	0.09 ~ 0.13 mm (0.0035 ~ 0.0051 in)	----
Valve clearance—exhaust (cold)	0.16 ~ 0.20 mm (0.0063 ~ 0.0079 in)	----
Valve dimensions		
 Head Diameter	 Face Width	 Seat Width
		 Margin Thickness
Valve head diameter "A"		
Intake	37.90 ~ 38.10 mm (1.4921 ~ 1.5000 in)	----
Exhaust	31.90 ~ 32.10 mm (1.2559 ~ 1.2638 in)	----
Valve face width "B"		
Intake	2.26 mm (0.0890 in)	----
Exhaust	2.26 mm (0.0890 in)	----
Valve seat width "C"		
Intake	1.00 ~ 1.20 mm (0.0394 ~ 0.0472 in)	1.60 mm (0.0630 in)
Exhaust	1.00 ~ 1.20 mm (0.0394 ~ 0.0472 in)	1.60 mm (0.0630 in)
Valve margin thickness "D"		
Intake	0.80 ~ 1.20 mm (0.0315 ~ 0.0472 in)	----
Exhaust	0.80 ~ 1.20 mm (0.0315 ~ 0.0472 in)	----
Valve stem diameter		
Intake	5.975 ~ 5.990 mm (0.2352 ~ 0.2358 in)	5.945 mm (0.2341 in)
Exhaust	5.960 ~ 5.975 mm (0.2346 ~ 0.2352 in)	5.930 mm (0.2335 in)
Valve guide inside diameter		
Intake	6.000 ~ 6.012 mm (0.2362 ~ 0.2367 in)	6.050 mm (0.2382 in)
Exhaust	6.000 ~ 6.012 mm (0.2362 ~ 0.2367 in)	6.050 mm (0.2382 in)





Item	Standard	Limit
Valve-stem-to-valve-guide clearance		
Intake	0.010 ~ 0.037 mm (0.0004 ~ 0.0015 in)	0.080 mm (0.0031 in)
Exhaust	0.025 ~ 0.052 mm (0.0010 ~ 0.0020 in)	0.100 mm (0.0039 in)
Valve stem runout	----	0.040 mm (0.0016 in)
		
Valve seat width		
Intake	1.00 ~ 1.20 mm (0.0394 ~ 0.0472 in)	1.60 mm (0.0630 in)
Exhaust	1.00 ~ 1.20 mm (0.0394 ~ 0.0472 in)	1.60 mm (0.0630 in)
Valve spring		
Free length		
Intake	38.79 mm (1.53 in)	36.85 mm (1.45 in)
Exhaust	38.79 mm (1.53 in)	36.85 mm (1.45 in)
Installed length (valve closed)		
Intake	35.00 mm (1.38 in)	----
Exhaust	35.00 mm (1.38 in)	----
Compressed spring force (installed)		
Intake	169 ~ 199 N (17.23 ~ 20.29 kgf, 37.99 ~ 44.73 lb)	----
Exhaust	169 ~ 199 N (17.23 ~ 20.29 kgf, 37.99 ~ 44.73 lb)	----
Spring tilt *		
		
Intake	----	2.5°/1.70 mm (2.5°/0.067 in)
Exhaust	----	2.5°/1.70 mm (2.5°/0.067 in)
Winding direction (top view)		
Intake	Clockwise	----
Exhaust	Clockwise	----



Item	Standard	Limit
Piston		
Piston-to-cylinder clearance	0.030 ~ 0.055 mm (0.0012 ~ 0.0022 in)	0.13 mm (0.0051 in)
Diameter "D"	101.955 ~ 101.970 mm (4.0140 ~ 4.0146 in)	----
		
Height "H"	10.0 mm (0.39 in)	----
Offset	0.50 mm (0.0197 in)	----
Offset direction	Intake side	----
Piston pin bore inside diameter	23.004 ~ 23.015 mm (0.9057 ~ 0.9061 in)	23.045 mm (0.9073 in)
Piston pin outside diameter	22.991 ~ 23.000 mm (0.9052 ~ 0.9055 in)	22.971 mm (0.9044 in)
Piston-pin-to-piston-pin-bore clearance	0.004 ~ 0.024 mm (0.0002 ~ 0.0009 in)	0.074 mm (0.0029 in)
Piston rings		
Top ring		
		
Ring type	Barrel	----
Dimensions (B × T)	1.20 × 3.80 mm (0.05 × 0.15 in)	----
End gap (installed)	0.20 ~ 0.35 mm (0.008 ~ 0.014 in)	0.60 mm (0.024 in)
Ring side clearance	0.030 ~ 0.070 mm (0.0012 ~ 0.0028 in)	0.12 mm (0.0047 in)
2nd ring		
		
Ring type	Taper	----
Dimensions (B × T)	1.20 × 4.00 mm (0.05 × 0.16 in)	----
End gap (installed)	0.75 ~ 0.90 mm (0.030 ~ 0.035 in)	1.25 mm (0.049 in)
Ring side clearance	0.030 ~ 0.070 mm (0.0012 ~ 0.0028 in)	0.13 mm (0.0051 in)




Item	Standard	Limit
Oil ring  Dimensions (B × T) End gap (installed) Ring side clearance	2.50 × 2.80 mm (0.10 × 0.11 in) 0.20 ~ 0.70 mm (0.008 ~ 0.028 in) 0.060 ~ 0.150 mm (0.0024 ~ 0.0059 in)	---- ---- ----
Crankshaft  Crank width "A" Maximum runout "C" Big end side clearance "D" Big end radial clearance "E" Small end free play "F"	74.95 ~ 75.00 mm (2.951 ~ 2.953 in) ---- 0.350 ~ 0.650 mm (0.0138 ~ 0.0256 in) 0.010 ~ 0.025 mm (0.0004 ~ 0.0010 in) 0.16 ~ 0.40 mm (0.0063 ~ 0.0157 in)	---- 0.030 mm (0.0012 in) 1.0 mm (0.04 in) ---- ----
Balancer Balancer drive method	Gear	----
Automatic centrifugal clutch Clutch shoe thickness Clutch-in revolution Clutch-stall revolution	1.5 mm (0.06 in) 1,850 ~ 2,250 r/min 3,500 ~ 4,100 r/min	1.0 mm (0.04 in) ---- ----
Transmission Maximum main axle runout Maximum drive axle runout	---- ----	0.06 mm (0.0024 in) 0.06 mm (0.0024 in)
Shifting mechanism Shift mechanism type	Shift drum and guide bar	----
Decompression device Device type	Auto decomp	----
Air filter oil grade	Foam air filter oil or equivalent oil	----
Throttle body Model/manufacturer × quantity Engine idle speed Intake vacuum	44EIS/MIKUNI × 1 1,350 ~ 1,450 r/min 35.0 kPa (263 mmHg, 10.3 inHg)	---- ---- ----



Item	Standard	Limit
Fuel pump		
Pump type	Electrical	----
Model/manufacturer	3B4/DENSO	----
Oil filter type		
	Cartridge (paper)	----
Oil pump		
Oil pump type	Trochoid	----
Inner-rotor-to-outer-rotor-tip clearance	Less than 0.12 mm (0.0047 in)	0.20 mm (0.0079 in)
Outer-rotor-to-oil-pump-housing clearance	0.090 ~ 0.170 mm (0.0035 ~ 0.0067 in)	0.24 mm (0.0094 in)
Oil-pump-housing-to-inner-and-outer-rotor clearance	0.03 ~ 0.10 mm (0.0012 ~ 0.0039 in)	0.17 mm (0.0067 in)
Oil pressure (hot)	50.0 kPa at 1,600 r/min (0.50 kg/cm ² at 1,600 r/min, 7.1 psi at 1,600 r/min)	----
Pressure check location	Cylinder head	----
Cooling system		
Radiator core		
Width	340.0 mm (13.39 in)	----
Height	248.2 mm (9.77 in)	----
Depth	22.0 mm (0.87 in)	----
Radiator cap opening pressure	93.3 ~ 122.7 kPa (0.933 ~ 1.227 kg/cm ² , 13.27 ~ 17.45 psi)	----
Coolant reservoir capacity		
Up to the maximum level mark	0.17 L (0.15 Imp qt, 0.18 US qt)	----
From low to full level	0.14 L (0.12 Imp qt, 0.15 US qt)	----
Water pump		
Water pump type	Single-suction centrifugal pump	----
Reduction ratio	32/31 (1.032)	----
Shaft drive		
Middle gear backlash	0.10 ~ 0.30 mm (0.004 ~ 0.012 in)	----
Final gear backlash	0.10 ~ 0.20 mm (0.0039 ~ 0.0079 in)	----
Differential gear backlash	0.05 ~ 0.25 mm (0.0020 ~ 0.0098 in)	----



Cylinder head tightening sequence





EBS01003

CHASSIS SPECIFICATIONS

Item	Standard	Limit
Steering system		
Steering bearing type	Ball and race bearing	----
Steering tension	50 N (5.0 kgf)	----
Front suspension		
Shock absorber travel	90.7 mm (3.57 in)	----
Spring free length	292.0 mm (11.50 in)	----
Installed length	237.0 mm (9.33 in)	----
Spring rate (K1)	23.00 N/mm (2.35 kg/mm, 131.33 lb/in)	----
Spring stroke (K1)	0 ~ 90.7 mm (0 ~ 3.57 in)	----
Optional spring available	No	----
Rear suspension		
Shock absorber travel	109.2 mm (4.30 in)	----
Spring free length	314.5 mm (12.38 in)	----
Installed length	271.0 mm (10.67 in)	----
Spring rate (K1)	33.50 N/mm (3.42 kg/mm, 191.28 lb/in)	----
Spring rate (K2)	36.00 N/mm (3.67 kg/mm, 205.56 lb/in)	----
Spring stroke (K1)	0 ~ 46.5 mm (0 ~ 1.83 in)	----
Spring stroke (K2)	46.5 ~ 109.2 mm (1.83 ~ 4.30 in)	----
Optional spring available	No	----
Front wheel		
Type	Panel wheel	----
Rim size	12 × 6.0 AT	----
Rim material	Aluminum	----
Maximum radial wheel runout	----	2.0 mm (0.08 in)
Maximum lateral wheel runout	----	2.0 mm (0.08 in)
Rear wheel		
Type	Panel wheel	----
Rim size	12 × 7.5 AT	----
Rim material	Aluminum	----
Maximum radial wheel runout	----	2.0 mm (0.08 in)
Maximum lateral wheel runout	----	2.0 mm (0.08 in)



Item	Standard	Limit
Front disc brake		
Type	Dual	----
Disc outside diameter × thickness	220.0 × 3.5 mm (8.66 × 0.14 in)	----
Brake disc minimum thickness	3.0 mm (0.12 in)	----
Brake disc maximum deflection	0.1 mm (0.004 in)	----
Pad thickness inner	4.4 mm (0.17 in)	1.0 mm (0.04 in)
Pad thickness outer	4.4 mm (0.17 in)	1.0 mm (0.04 in)
Master cylinder inside diameter	12.70 mm (0.50 in)	----
Caliper cylinder inside diameter	33.96 mm (1.34 in)	----
Brake fluid type	DOT 4	----
Rear disc brake		
Type	Dual	----
Disc outside diameter × thickness	205.0 × 3.5 mm (8.07 × 0.14 in)	----
Brake disc minimum thickness	3.0 mm (0.12 in)	----
Brake disc maximum deflection	0.1 mm (0.004 in)	----
Pad thickness inner	5.8 mm (0.23 in)	1.0 mm (0.04 in)
Pad thickness outer	5.8 mm (0.23 in)	1.0 mm (0.04 in)
Master cylinder inside diameter	12.70 mm (0.50 in)	----
Caliper cylinder inside diameter	33.96 mm (1.34 in)	----
Brake fluid type	DOT 4	----
Brake lever and brake pedal		
Brake pedal position	56.7 mm (2.23 in)	----
Brake pedal free play	0 ~ 5.0 mm (0 ~ 0.20 in)	----
Throttle lever free play	3.0 ~ 5.0 mm (0.12 ~ 0.20 in)	----



EBS01004

ELECTRICAL SPECIFICATIONS

Item	Standard	Limit
System voltage	12 V	----
Ignition system		
Ignition timing (B.T.D.C.)	12°/1,400 r/min	----
Advancer type	Digital	----
Transistorized coil ignition		
Crankshaft position sensor resistance/color	459 ~ 561 Ω at 20 °C (68 °F)/ black-green/yellow	----
ECU		
Model/manufacture	3B4/MITSUBISHI	----
Ignition coil		
Model/manufacture	JO226/DENSO	----
Minimum ignition spark gap	6.0 mm (0.24 in)	----
Primary coil resistance	3.4 ~ 4.6 Ω at 20 °C (68 °F)	----
Secondary coil resistance	10.4 ~ 15.6 kΩ at 20 °C (68 °F)	----
Spark plug cap		
Material	Resin	----
Resistance	10.0 kΩ	----
AC magneto		
Model/manufacture	F4T393/MITSUBISHI	----
Standard output	14.0 V 35.0 A at 5,000 r/min	----
Stator coil resistance/color	0.108 ~ 0.132 Ω at 20 °C (68 °F)/ white-white	----
Rectifier/regulator		
Type	Semiconductor-short-circuit	----
Model/manufacture	FH012AA/SHINDENGEN	----
No load regulated voltage (DC)	14.2 ~ 14.8 V	----
Rectifier capacity	50.0 A	----
Withstand voltage	40.0 V	----
Electric starting system		
Type	Constant mesh	----
Starter motor		
Model/manufacture	SM-13/MITSUBA	----
Power output	0.80 kW	----
Armature coil resistance	0.0250 ~ 0.0350 Ω at 20 °C (68 °F)	----
Brush overall length	12.5 mm (0.49 in)	5.00 mm (0.20 in)
Spring force	7.65 ~ 10.01 N (780 ~ 1,021 gf, 27.54 ~ 36.03 oz)	----
Commutator diameter	28.0 mm (1.10 in)	27.0 mm (1.06 in)
Mica undercut	0.70 mm (0.03 in)	----



Item	Standard	Limit
Starter relay		
Model/manufacturer	2768113-A/JIDECO	----
Amperage rating	180.0 A	----
Coil winding resistance	4.18 ~ 4.62 Ω at 20 °C (68 °F)	----
Fuel gauge		
Sender unit resistance (full)	19.00 ~ 21.00 Ω	----
Sender unit resistance (empty)	139.00 ~ 141.00 Ω	----
Starting circuit cut-off relay		
Model/manufacturer	ACM33211/MATSUSHITA	----
Coil resistance	96.0 Ω	----
Radiator fan motor relay		
Model/manufacturer	ACM33211/MATSUSHITA	----
Coil resistance	96.0 Ω	----
Circuit breaker		
Circuit breaker type	Fuse	----
Fuses		
Main fuse	40.0 A	----
Headlight fuse	15.0 A	----
Signaling system fuse	5.0 A	----
Ignition fuse	10.0 A	----
Auxiliary DC jack fuse	15.0 A	----
Fuel injection system fuse	15.0 A	----
Four-wheel-drive motor fuse	10.0 A	----
EPS fuse	40.0 A	----
Radiator fan motor fuse	15.0 A	----
Spare fuse	40.0 A	----
	15.0 A	----
	10.0 A	----
	5.0 A	----



EBS01005

TIGHTENING TORQUES

ENGINE TIGHTENING TORQUES

Item	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m · kg	ft · lb	
Cylinder head (exhaust pipe)	Stud bolt	M8	4	15	1.5	11	
Cylinder head	Bolt	M9	4	35	3.5	25	
Cylinder head	Bolt	M9	2	38	3.8	27	
Cylinder head	Bolt	M6	2	10	1.0	7.2	
Spark plug	—	M10	1	13	1.3	9.4	
Oil gallery bolt	Union bolt	M8	1	10	1.0	7.2	
Cylinder	Bolt	M10	4	50	5.0	36	See NOTE.
AC magneto rotor	Nut	M16	1	70	7.0	50	
Balancer driven gear	Nut	M18	1	80	8.0	58	Use a lock washer.
Thermostat cover	Bolt	M6	2	10	1.0	7.2	
Cylinder head air bleed bolt	Bolt	M6	1	10	1.0	7.2	
Valve adjusting screw	Nut	M6	4	14	1.4	10	
Decompression assembly	Bolt	M7	2	20	2.0	14	
Timing chain guide (intake side)	Bolt	M6	2	10	1.0	7.2	
Timing chain tensioner cap	Bolt	M16	1	20	2.0	14	
Timing chain tensioner	Bolt	M6	2	10	1.0	7.2	
Bearing retainer (camshaft)	Bolt	M6	2	10	1.0	7.2	
Camshaft sprocket cover	Bolt	M6	2	10	1.0	7.2	
Tappet cover	Bolt	M6	8	10	1.0	7.2	
Camshaft sprocket	Bolt	M7	2	20	2.0	14	
Crankcase	Bolt	M8	2	26	2.6	19	
	Bolt	M6	4	10	1.0	7.2	
	Bolt	M6	8	10	1.0	7.2	
Engine oil drain bolt	Bolt	M14	1	30	3.0	22	
Oil filter cartridge	—	M20	1	17	1.7	12	
Oil filter cartridge union bolt	Union bolt	M20	1	68	6.8	49	
Oil delivery pipe	Union bolt	M14	2	35	3.5	25	
Oil delivery pipe	Union bolt	M10	1	20	2.0	14	
Oil pump	Bolt	M6	3	10	1.0	7.2	
Oil pump driven gear	Nut	M10	1	22	2.2	16	Use a lock washer.
Bearing retainer (crankcase)	Bolt	M6	2	10	1.0	7.2	
Exhaust pipe protector	Bolt	M6	2	7	0.7	5.1	
Muffler and frame	Bolt	M8	1	20	2.0	14	
Muffler and muffler bracket	Bolt	M8	2	20	2.0	14	
Exhaust pipe	Nut	M8	4	20	2.0	14	
Water pump housing	Bolt	M6	2	10	1.0	7.2	
Coolant drain bolt	Bolt	M6	1	10	1.0	7.2	
Water pump air bleed bolt	Bolt	M6	1	10	1.0	7.2	

TIGHTENING TORQUES

SPEC



Item	Part name	Thread size	Q'ty	Tightening torque			Remarks
				Nm	m · kg	ft · lb	
Water pump outlet pipe	Bolt	M6	1	10	1.0	7.2	
Water jacket joint	Bolt	M6	2	10	1.0	7.2	
Timing chain guide	Bolt	M6	2	10	1.0	7.2	
Crankshaft end accessing screw	—	M36	1	10	1.0	7.2	
Timing mark accessing screw	—	M14	1	6	0.6	4.3	
Drive belt cover	Bolt	M6	12	10	1.0	7.2	
Bearing housing (primary sheave assembly)	Bolt	M6	4	10	1.0	7.2	
AC magneto/crankshaft position sensor lead holder	Bolt	M5	2	7	0.7	5.1	
Starter one-way clutch	Screw	M8	3	30	3.0	22	
Clutch housing assembly	Bolt	M6	9	10	1.0	7.2	
Clutch carrier assembly	Nut	M22	1	190	19.0	140	Left-hand thread Stake.
Middle drive pinion gear nut	Nut	M22	1	180	18.0	130	Stake.
Middle driven shaft bearing housing	Bolt	M8	4	32	3.2	23	
Middle drive shaft bearing retainer	Bolt	M6	4	29	2.9	21	
Front drive shaft coupling gear nut (middle gear side)	Nut	M16	1	115	11.5	85	
Middle driven shaft bearing retainer	Nut	M55	1	80	8.0	58	Left-hand thread
Middle driven pinion gear bearing retainer	Nut	M60	1	130	13.0	94	Left-hand thread
Rear drive shaft coupling gear nut (middle gear side)	Nut	M16	1	150	15.0	110	
Middle driven pinion gear bearing housing	Bolt	M8	4	25	2.5	18	
Primary sheave assembly	Nut	M16	1	140	14.0	100	
Secondary sheave spring retainer	Nut	M36	1	90	9.0	65	
Secondary sheave assembly	Nut	M16	1	100	10.0	72	
Shift lever 2 assembly	Bolt	M6	1	14	1.4	10	
Shift drum stopper	Bolt	M14	1	18	1.8	13	
Stopper lever stopper	Bolt	M14	1	18	1.8	13	
Stator coil assembly	Bolt	M6	3	7	0.7	5.1	
Crankshaft position sensor	Bolt	M5	2	7	0.7	5.1	
Coolant temperature sensor	—	M12	1	18	1.8	13	
Gear position switch	Bolt	M6	2	7	0.7	5.1	
Reverse switch	—	M10	1	17	1.7	12	
Speed sensor	Bolt	M6	1	10	1.0	7.2	

**NOTE:**



Temporarily tighten the cylinder bolts to 15 Nm (1.5 m · kg, 11 ft · lb) and then tighten them to 50 Nm (5.0 m · kg, 36 ft · lb).

EBS01006

CHASSIS TIGHTENING TORQUES

Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Engine and front rubber damper	M10	42	4.2	30	
Engine and front rubber damper	M6	10	1.0	7.2	
Engine and rear rubber damper	M10	42	4.2	30	
Engine and rear rubber damper	M6	10	1.0	7.2	
Rubber damper and frame	M10	42	4.2	30	
Differential gear case and frame	M10	55	5.5	40	
Differential gear case and frame	M10	55	5.5	40	
Final gear case and frame	M10	55	5.5	40	
Radiator and frame	M6	7	0.7	5.1	
Coolant reservoir and frame	M6	7	0.7	5.1	
Shift arm	M6	14	1.4	10	
Select lever shift rod locknut	M8	15	1.5	11	
Select lever unit and frame	M6	7	0.7	5.1	
Select lever guide and frame	M6	7	0.7	5.1	
Front grill and front grill bracket	M6	7	0.7	5.1	
Front grill bracket and frame	M6	7	0.7	5.1	
Front fender and frame	M6	7	0.7	5.1	
Rear fender and frame	M6	7	0.7	5.1	
Radiator bracket and frame	M6	7	0.7	5.1	
Rear upper arm and frame	M10	45	4.5	32	
Rear lower arm and frame	M10	45	4.5	32	
Rear shock absorber and frame	M10	45	4.5	32	
Rear shock absorber and rear lower arm	M10	45	4.5	32	
Rear knuckle and rear upper arm	M10	45	4.5	32	
Rear knuckle and rear lower arm	M10	45	4.5	32	
Rear brake hose guide and rear lower arm	M6	7	0.7	5.1	
Stabilizer joint and stabilizer	M10	50	5.0	36	
Stabilizer joint and rear lower arm	M10	50	5.0	36	
Stabilizer holder and frame	M8	30	3.0	22	
Rear arm protector and rear lower arm	M6	7	0.7	5.1	
Front upper arm and frame	M10	45	4.5	32	
Front lower arm and frame	M10	45	4.5	32	
Front shock absorber and frame	M10	45	4.5	32	
Front shock absorber and front lower arm	M10	45	4.5	32	
Front brake hose holder and front upper arm	M6	7	0.7	5.1	
Select lever shift rod end	M10	15	1.5	11	Left-hand thread
Steering stem bushing and steering stem bracket	M8	23	2.3	17	
Steering stem joint bolt	M8	30	3.0	22	
EPS unit and frame	M8	30	3.0	22	
Steering stem bracket and frame	M10	50	5.0	36	
Steering stem bearing and frame	M10	50	5.0	36	



Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Pitman arm nut	M16	210	21.0	150	
EPS motor cover	M6	7	0.7	5.1	
Pitman arm and tie-rod	M10	25	2.5	18	
Steering knuckle and tie-rod	M10	25	2.5	18	
Steering knuckle and front lower arm	M12	30	3.0	22	
Front arm protector and front lower arm	M6	7	0.7	5.1	
Fuel tank and fuel pump	M6	7	0.7	5.1	
Fuel tank and frame	M6	7	0.7	5.1	
Fuel tank side cover and frame	M6	7	0.7	5.1	
Front wheel and front wheel hub	M10	55	5.5	40	
Front wheel axle nut	M20	260	26.0	190	Stake.
Front brake caliper and steering knuckle	M8	30	3.0	22	
Front brake caliper bleed screw	M8	5	0.5	3.6	
Front brake disc and front wheel hub	M8	30	3.0	22	
Rear brake disc and rear wheel hub	M8	30	3.0	22	
Rear wheel and rear wheel hub	M10	55	5.5	40	
Rear wheel axle nut	M20	260	26.0	190	Stake.
Rear brake caliper and rear knuckle	M8	30	3.0	22	
Rear brake caliper bleed screw	M8	5	0.5	3.6	
Brake pad holding bolt	M6	17	1.7	12	
Rear knuckle and brake disc guard	M6	7	0.7	5.1	
Steering knuckle and brake disc guard	M6	7	0.7	5.1	
Brake master cylinder and brake master cylinder holder	M6	7	0.7	5.1	
Brake lever pivot	M6	6	0.6	4.3	Silicone grease
Handlebar holder and steering shaft	M8	20	2.0	14	
Brake hose joint and frame	M6	10	1.0	7.2	
Brake hose joint and brake hose	M10	19	1.9	13	
Brake hose union bolt	M10	27	2.7	19	
Rear knuckle and brake hose protector	M6	7	0.7	5.1	
Footrest bracket and frame	M10	53	5.3	38	
Footrest board and footrest bracket	M6	7	0.7	5.1	
Footrest and footrest board	M6	7	0.7	5.1	
Brake pedal adjusting nut	M6	7	0.7	5.1	
Shift control cable and shift lever cover	M14	17	1.7	12	
Front guard and frame	M8	26	2.6	19	
Front carrier and front guard	M8	26	2.6	19	
Front carrier and front carrier bracket	M8	26	2.6	19	
Front carrier bracket and frame	M8	26	2.6	19	
Front carrier and front fender	M6	7	0.7	5.1	
Rear carrier and rear carrier bracket	M8	34	3.4	24	
Rear carrier bracket and frame	M10	48	4.8	35	



Part to be tightened	Thread size	Tightening torque			Remarks
		Nm	m · kg	ft · lb	
Rear carrier and rear fender	M6	7	0.7	5.1	
Engine skid plates	M6	7	0.7	5.1	
Trailer hitch and frame	M10	55	5.5	40	
Battery holding bracket	M6	7	0.7	5.1	
Battery bracket and fitting screw	M6	7	0.7	5.1	
Fitting screw and frame	M6	7	0.7	5.1	
Electrical components tray and frame	M6	7	0.7	5.1	
Differential gear case filler bolt	M14	23	2.3	17	
Differential gear case drain bolt	M10	10	1.0	7.2	
Differential gear case cover and differential gear case	M8	24	2.4	17	
Differential gear motor and differential gear case cover	M6	11	1.1	8.0	
Front drive shaft coupling gear and differential drive pinion gear	M14	62	6.2	45	
Final gear case filler plug	M14	23	2.3	17	
Final gear case drain bolt	M14	23	2.3	17	
Final gear oil level check bolt	M8	10	1.0	7.2	
Final gear case and final gear case cover	M8	23	2.3	17	
Final drive pinion gear bearing housing and final gear case	M8	23	2.3	17	

EBS00022

HOW TO USE THE CONVERSION TABLE

All specification data in this manual are listed in SI and METRIC UNITS.

Use this table to convert METRIC unit data to IMPERIAL unit data.

Ex.

METRIC		MULTIPLIER		IMPERIAL
** mm	×	0.03937	=	** in
2 mm	×	0.03937	=	0.08 in

CONVERSION TABLE

METRIC TO IMPERIAL			
	Metric unit	Multiplier	Imperial unit
Torque	m · kg	7.233	ft · lb
	m · kg	86.794	in · lb
	cm · kg	0.0723	ft · lb
	cm · kg	0.8679	in · lb
Weight	kg	2.205	lb
	g	0.03527	oz
Speed	km/hr	0.6214	mph
Distance	km	0.6214	mi
	m	3.281	ft
	m	1.094	yd
	cm	0.3937	in
	mm	0.03937	in
Volume/ Capacity	cc (cm ³)	0.03527	oz (IMP liq.)
	cc (cm ³)	0.06102	cu · in
	lt (liter)	0.8799	qt (IMP liq.)
	lt (liter)	0.2199	gal (IMP liq.)
Misc.	kg/mm	55.997	lb/in
	kg/cm ²	14.2234	psi (lb/in ²)
	Centigrade (°C)	9/5+32	Fahrenheit (°F)

EBS00023

GENERAL TIGHTENING TORQUE SPECIFICATIONS

This chart specifies tightening torques for standard fasteners with a standard ISO thread pitch. Tightening torque specifications for special components or assemblies are provided for each chapter of this manual. To avoid warpage, tighten multi-fastener assemblies in a crisscross pattern and progressive stages until the specified tightening torque is reached. Unless otherwise specified, tightening torque specifications require clean, dry threads. Components should be at room temperature.

A: Distance between flats

B: Outside thread diameter

A (nut)	B (bolt)	General tightening torques		
		Nm	m · kg	ft · lb
10 mm	6 mm	6	0.6	4.3
12 mm	8 mm	15	1.5	11
14 mm	10 mm	30	3.0	22
17 mm	12 mm	55	5.5	40
19 mm	14 mm	85	8.5	61
22 mm	16 mm	130	13.0	94



EBS00024

LUBRICATION POINTS AND LUBRICANT TYPES

ENGINE

Lubrication point	Lubricant
Oil seal lips	
Bearings	
O-ring	
Cylinder head bolts	
Crankshaft pin	
Connecting rod big end thrust surface	
Crankshaft sprocket	
Inner race (crankshaft)	
Buffer boss (crankshaft)	
Crankshaft seal	
Piston pin	
Piston and ring groove	
Valve stems (intake and exhaust)	
Valve stem ends (intake and exhaust)	
Rocker arm shafts	
Camshaft lobes	
Decompressor lever pin	
Decompressor lever spring	
Rocker arms (intake and exhaust)	
Oil pump shaft	
O-ring (oil filter cartridge)	
Water pump impeller shaft	
Dipstick mating surface	
Starter idler gear inner surface	
Starter idler gear shaft	
Starter wheel gear	
Torque limiter	
Clutch housing shaft end	
Clutch carrier assembly	
One-way clutch bearing	
Clutch dog and middle drive gear	
Reverse idle gear shaft	
Middle driven shaft splines	
Shift drum	
Shift forks and shift fork guide bar	
Ball (shift drum stopper)	
Stopper lever and stopper lever shaft	

LUBRICATION POINTS AND LUBRICANT TYPES

SPEC



Lubrication point	Lubricant
Shift lever 2 inner surface	
Shift lever 1	
Shift lever 1 gear teeth and shift lever 2 gear teeth	
Stopper lever stopper	
Bearing (final drive pinion gear assembly)	
Bearing (final gear)	
AC magneto lead grommet	Yamaha bond No.1215 (Three bond No.1215®)
Crankcase mating surface	Yamaha bond No.1215 (Three bond No.1215®)




EBS00025

COOLANT FLOW DIAGRAMS

- ① Coolant reservoir hose
- ② Radiator inlet hose
- ③ Fast idle plunger outlet hose
- ④ Coolant reservoir
- ⑤ Water pump
- ⑥ Water pump outlet pipe
- ⑦ Water pump outlet hose
- ⑧ Radiator outlet hose
- ⑨ Radiator

- ⑩ Fast idle plunger inlet hose






EBS00026


OIL FLOW DIAGRAMS

- ① Oil delivery pipe
- ② Oil filter cartridge
- ③ Oil strainer
- ④ Drive axle
- ⑤ Relief valve assembly
- ⑥ Reverse idle gear shaft





- ① Camshaft
- ② Crankshaft
- ③ Oil strainer
- ④ Oil pump rotor
- ⑤ Oil pump driven gear






EBS00028


CABLE ROUTING

- ① Front brake light switch lead
- ② On-command four-wheel-drive motor switch and differential gear lock switch lead
- ③ Front brake hose
- ④ Throttle cable
- ⑤ Rear brake cable
- ⑥ Shift control cable
- ⑦ Rear brake hose
- ⑧ Left handlebar switch lead
- ⑨ Rear brake light switch lead
- ⑩ Radiator fan motor breather hose
- ⑪ Differential gear case breather hose
- ⑫ EPS motor breather hose
- ⑬ Radiator fan motor lead
- ⑭ Meter assembly lead
- ⑮ Final gear case breather hose






- [A] Pass the front brake hose and throttle cable through the guide on the handlebar cover.
- [B] Pass the rear brake cable, shift control cable, and rear brake hose through the guide on the handlebar cover.
- [C] Route the rear brake cable, shift control cable, and rear brake hose in front of the left handlebar switch lead and rear brake light switch lead.
- [D] Pass the rear brake hose and throttle cable through the guide, making sure to route the cable behind the hose.
- [E] Pass the rear brake cable and shift control cable through the guide.
- [F] Pass the front brake hose through the guide.
- [G] Route the throttle cable behind the rear brake cable and shift control cable.





H Route the front brake light switch lead, on-command four-wheel-drive motor switch and differential gear lock switch lead, left handlebar switch lead, and rear brake light switch lead over the throttle cable, rear brake cable, and shift control cable, then to the front of where the cables cross.


- I Fasten the left handlebar switch lead and rear brake light switch lead with the plastic bands at the bends in the handlebar, making sure to route the leads under the handlebar and to face the ends of the bands forward.
- J Pass the radiator fan motor breather hose through the guide on the meter bracket, making sure to face the end of the hose downward.
- K Pass the differential gear case breather hose through the guide on the meter bracket, making sure to face the end of the hose downward.






- [L] Pass the EPS motor breather hose through the guide on the meter bracket, making sure to face the end of the hose downward.
- [M] Route the radiator fan motor breather hose and differential gear case breather hose in front of the frame.
- [N] Fasten the differential gear case breather hose to the frame with the plastic band, making sure to face the end of the band inward.
- [O] Route the differential gear case breather hose to the inside of the frame.

- [P] Fasten the front brake light switch lead, on-command four-wheel-drive motor switch and differential gear lock switch lead, left handlebar switch lead, and rear brake light switch lead with a plastic locking tie. Be sure to fasten the plastic locking tie above the couplers and fasten it around the protective sleeves of the leads, not the leads themselves.
- [Q] Pass the final gear case breather hose through the guide on the meter bracket, making sure to face the end of the hose downward.





- [R] Fasten the front brake light switch lead and on-command four-wheel-drive motor switch and differential gear lock switch lead with the plastic bands at the bends in the handlebar, making sure to route the leads under the handlebar and to face the ends of the bands forward.
- [S] 20 ~ 50 mm (0.79 ~ 1.97 in)






- ① Coolant reservoir hose
- ② Radiator fan motor breather hose
- ③ Differential gear case breather hose
- ④ EPS motor breather hose
- ⑤ Ground lead
- ⑥ Coolant reservoir breather hose
- ⑦ Throttle cable
- ⑧ Fuel injector lead
- ⑨ Final gear case breather hose
- ⑩ Speed sensor lead
- ⑪ Crankshaft position sensor lead

- ⑫ Differential gear motor lead
- ⑬ EPS torque sensor lead
- ⑭ Fast idle plunger outlet hose
- ⑮ Radiator outlet hose
- ⑯ Gear position switch lead
- ⑰ Reverse switch lead
- ⑱ Shift control cable
- ⑲ Starter motor lead


A Face the end of the coolant reservoir breather hose downward.





- [B] Route the ground lead, radiator fan motor breather hose, differential gear case breather hose, and EPS motor breather hose to the inside of the fast idle plunger outlet hose.
- [C] Pass the radiator fan motor breather hose through the larger diameter guide.
- [D] Route the coolant reservoir breather hose to the outside of the fast idle plunger outlet hose.
- [E] Route the fuel injector lead under the fuel hose.


- [F] Fasten the radiator outlet hose to the frame with the plastic band, making sure to face the end of the band inward.
- [G] Route the EPS motor breather hose under the coolant reservoir hose.
- [H] Place the EPS torque sensor lead and differential gear motor lead in the holder, and then insert the ends of the holder into the hole in the stay on the frame.
- [I] Route the differential gear case breather hose to the inside of the frame.






- J Fasten the differential gear case breather hose to the frame with the plastic band, making sure to face the end of the band inward.
- K Attach the ground lead terminal to the frame using the bolt.
- L Route the radiator fan motor breather hose and differential gear case breather hose to the inside of the fast idle plunger outlet hose and radiator outlet hose.
- M Make sure that the catch of the holder is facing outward.

- N Face the end of the plastic band inward.
- O Route the fuel tank drain hose and position the end of the hose as shown in the illustration.
- P Pass the speed sensor lead, AC magneto lead, and final gear case breather hose through the guide in the order listed.
- Q Route the speed sensor lead, AC magneto lead, and final gear case breather hose to the right of the reverse switch.
- R Route the final gear case breather hose above the reverse switch lead and ground leads.






[S] Route the shift control cable under the gear position switch lead, speed sensor lead, and crankshaft position sensor lead.





- ① Wire harness
- ② Fuel injector lead
- ③ Fuel hose
- ④ Intake air temperature sensor lead
- ⑤ Final gear case breather hose
- ⑥ Ground lead
- ⑦ Starter motor lead
- ⑧ Air filter case breather hose
- ⑨ Main switch lead
- ⑩ Auxiliary DC jack lead
- ⑪ EPS motor lead
- ⑫ Differential gear motor lead
- ⑬ EPS torque sensor lead
- ⑭ Radiator fan motor lead
- ⑮ Radiator inlet hose
- ⑯ EPS motor breather hose
- ⑰ Spark plug lead
- ⑱ Rear brake cable
- ⑲ Shift control cable
- ⑳ Fuel tank drain hose
- ㉑ Gear position switch lead
- ㉒ AC magneto lead






- ⑳ Speed sensor lead
- ㉑ Coolant temperature sensor lead
- ㉒ EPS motor lead coupler
- ㉓ EPS torque sensor lead coupler

- A Route the fuel hose between the wire harness and the fuel tank drain hose.
- B Route the coolant temperature sensor lead above the fast idle plunger inlet hose.
- C Route the final gear case breather hose above the V-belt cooling duct 1.


- D Route the radiator fan motor lead between the electrical components tray and the radiator inlet hose.
- E Fasten the radiator fan motor lead to the frame with the plastic band, making sure to face the end of the band inward.
- F Route the fuel tank drain hose to the inside of the leads and fuel hose, making sure to position the end of the drain hose as shown in the illustration.





- G Fasten the final gear case breather hose, ground lead, starter motor lead, fuel injector lead, coolant temperature sensor lead, AC magneto lead, and wire harness with the plastic band, making sure to position the band near the split in the wire harness.
- H Route the fuel injector lead and coolant temperature sensor lead to the inside of the ground lead, starter motor lead, final drive gear case breather hose, and wire harness.


- I Face the end of the plastic band inward.
- J Pass the plastic band through the hole in the plastic cover, and then fasten the leads and hose with the band, making sure to face the end of the band downward.
- K Insert the projection on the coupler into the hole in the frame from the inside of the frame.
- L Face the end of the plastic band inward.
- M Fasten the spark plug lead with the larger diameter section of each holder.





- ① Tail/brake light lead
- ② Rectifier/regulator lead
- ③ AC magneto lead
- ④ Speed sensor lead
- ⑤ Final gear case breather hose
- ⑥ Fuel hose
- ⑦ Fuel pump lead
- ⑧ Wire harness


- [A] To tail/brake light
- [B] Fasten the tail/brake light lead to the frame with a plastic locking tie, making sure to face the end of the tie downward.
- [C] Install the plastic band near the split in the wire harness.
- [D] Route the tail/brake light lead to the outside of the frame.
- [E] Face the end of the plastic band downward.
- [F] Pass the final gear case breather hose through the guide.





- ① Left headlight lead
- ② Negative battery lead
- ③ Right headlight lead
- ④ Radiator fan motor lead
- ⑤ EPS control unit lead
- ⑥ Auxiliary DC jack lead
- ⑦ Main switch lead
- ⑧ Final gear case breather hose
- ⑨ Starter motor lead
- ⑩ Differential gear motor lead
- ⑪ Ignition coil lead

- ⑫ Meter lead
- ⑬ Lean angle sensor lead
- ⑭ Coolant reservoir breather hose
- ⑮ Positive battery lead
- ⑯ Coolant reservoir hose
- ⑰ EPS motor breather hose
- ⑱ Differential gear case breather hose
- ⑲ Radiator fan motor breather hose
- ⑳ Ground lead
- ㉑ Relay lead
- ㉒ Wire harness





⑳ Joint coupler lead

Ⓐ To left headlight

Ⓑ Connect the headlight lead coupler, and then fasten the coupler with the holder on the electrical components tray.

Ⓒ Route the negative battery lead along the guide on the electrical components tray.

Ⓓ To right headlight


Ⓔ Place the couplers on the inside of the electrical components tray.

Ⓕ To main switch and auxiliary DC jack

Ⓖ Fasten the left handlebar switch lead, on-command four-wheel-drive motor switch and differential gear lock switch lead, front brake light switch lead, and rear brake light switch lead with the clamp.

Ⓗ Fasten the joint coupler lead with the clamp.


Ⓙ Pass the coolant reservoir breather hose through the guides on the plastic cover and electrical components tray and route it under the positive battery lead and starter motor lead.





- J Route the hoses under the positive battery lead, and then route them upward, to the inside of the coolant reservoir breather hose.
- K Fasten the coolant reservoir breather hose with the holder on the electrical components tray.
- L Fasten the coolant reservoir hose with the holder on the electrical components tray.
- M Pass the hoses and ground lead through the opening in the electrical components tray.
- N Route the coolant reservoir breather hose above the other hoses.

- O Route the hoses to the inside of the bolt.






- ① Throttle cable
- ② Rear brake hose
- ③ Rear brake cable
- ④ Front brake hose
- ⑤ Negative battery lead
- ⑥ Final gear case breather hose
- ⑦ Starter motor lead
- ⑧ Intake air pressure sensor lead
- ⑨ TPS lead
- ⑩ Intake air temperature sensor lead
- ⑪ Fuel injector lead


- ⑫ Coolant temperature sensor lead
- ⑬ Rectifier/regulator lead
- ⑭ AC magneto lead
- ⑮ Fuel hose
- ⑯ Tail/brake light lead
- ⑰ Fuel pump lead
- ⑱ Fast idle plunger outlet hose
- ⑲ Wire harness

A Route the final gear case breather hose on top of the leads.





- [B] To engine
- [C] To air filter case
- [D] Route the fuel injector lead and coolant temperature sensor lead to the outside of the frame.
- [E] Pass the tail/brake light lead through the hole in the rear fender.
- [F] Fasten the tail/brake light lead with the holder, making sure that the coupler is positioned to the rear of the holder.
- [G] Route the throttle cable under the plastic cover.
- [H] Route the fast idle plunger outlet hose above the plastic cover.
- [I] Pass the throttle cable through the guide on the plastic cover.
- [J] Insert the projection on the wire harness holder into the hole in the plastic cover.



EBS00029

PERIODIC CHECKS AND ADJUSTMENTS

INTRODUCTION

This chapter includes all information necessary to perform recommended checks and adjustments. These preventive maintenance procedures, if followed, will ensure more reliable vehicle operation and a longer service life. The need for costly overhaul work will be greatly reduced. This information applies to vehicles already in service as well as to new vehicles that are being prepared for sale. All service technicians should be familiar with this entire chapter.

EBS00029

PERIODIC MAINTENANCE CHART FOR THE EMISSION CONTROL SYSTEM

NOTE:

- For ATVs not equipped with an odometer or an hour meter, follow the month maintenance intervals.
- For ATVs equipped with an odometer or an hour meter, follow the km (mi) or hours maintenance intervals. However, keep in mind that if the ATV isn't used for a long period of time, the month maintenance intervals should be followed.
- Items marked with an asterisk should be performed by a Yamaha dealer as they require special tools, data and technical skills.

NO.	ITEM	CHECK OR MAINTENANCE JOB	Whichever comes first ⇒	INITIAL			EVERY		
				month	1	3	6	6	12
				km (mi)	320 (200)	1300 (800)	2500 (1600)	2500 (1600)	5000 (3200)
				hours	20	80	160	160	320
1	* Fuel line	• Check fuel hoses for cracks or other damage, and replace if necessary.				√	√	√	
2	Spark plug	• Check condition and clean, regap, or replace if necessary.		√	√	√	√	√	
3	* Valves	• Check valve clearance and adjust if necessary.		√		√	√	√	
4	* Fuel injection	• Check and adjust engine idle speed.		√	√	√	√	√	
5	* Crankcase breather system	• Check breather hose for cracks or other damage, and replace if necessary.				√	√	√	
6	* Exhaust system	• Check for leakage and replace gasket(s) if necessary. • Check for looseness and tighten all screw clamps and joints if necessary.				√	√	√	
7	Spark arrester	• Clean.				√	√	√	

GENERAL MAINTENANCE AND LUBRICATION CHART



EBU21863

GENERAL MAINTENANCE AND LUBRICATION CHART

NO.	ITEM	CHECK OR MAINTENANCE JOB	Whichever comes first ⇒	INITIAL			EVERY		
				month	1	3	6	6	12
				km (mi)	320 (200)	1300 (800)	2500 (1600)	2500 (1600)	5000 (3200)
				hours	20	80	160	160	320
1	Air filter element	• Clean and replace if necessary.		Every 20–40 hours (more often in wet or dusty areas)					
2	* Front brake	• Check operation and correct if necessary. • Check fluid level and ATV for fluid leakage, and correct if necessary.	√	√	√	√	√		
		• Replace brake pads.	Whenever worn to the limit						
3	* Rear brake	• Check operation and correct if necessary. • Check brake pedal free play and adjust if necessary. • Check fluid level and ATV for fluid leakage, and correct if necessary.	√	√	√	√	√		
		• Replace brake pads.	Whenever worn to the limit						
4	* Brake hoses	• Check for cracks or other damage, and replace if necessary.		√	√	√	√		
		• Replace.	Every 4 years						
5	* Rear brake hose protectors	• Check for wear, cracks or other damage, and replace if necessary.	√	√	√	√	√		
6	* Wheels	• Check runout and for damage, and replace if necessary.	√		√	√	√		
7	* Tires	• Check tread depth and for damage, and replace if necessary. • Check air pressure and balance, and correct if necessary.	√		√	√	√		
8	* Wheel bearings	• Check for looseness or damage, and replace if necessary.	√		√	√	√		
9	* Upper and lower arm pivots	• Lubricate with lithium-soap-based grease.			√	√	√		
10	* V-belt	• Check for wear, cracks or other damage, and replace if necessary.	√		√	√	√		
11	* Drive shaft universal joint	• Lubricate with lithium-soap-based grease.			√	√	√		
12	* Chassis fasteners	• Make sure that all nuts, bolts, and screws are properly tightened.	√	√	√	√	√		
13	* Shock absorber assemblies	• Check operation and correct if necessary. • Check for oil leakage and replace if necessary.			√	√	√		
14	* Stabilizer bushes	• Check for cracks or other damage, and replace if necessary.			√	√	√		
15	* Knuckle pivots	• Lubricate with lithium-soap-based grease.			√	√	√		
16	* Knuckle shafts	• Lubricate with lithium-soap-based grease.			√	√	√		
17	* Steering shaft	• Lubricate with lithium-soap-based grease.			√	√	√		
18	* Steering system	• Check operation and repair or replace if damaged. • Check toe-in and adjust if necessary.	√	√	√	√	√		
19	* Engine mount	• Check for cracks or other damage, and replace if necessary.			√	√	√		
20	* Axle boots	• Check for cracks or other damage, and replace if necessary.	√	√	√	√	√		
21	Engine oil	• Change. • Check ATV for oil leakage, and correct if necessary.	√		√	√	√		

GENERAL MAINTENANCE AND LUBRICATION CHART



NO.	ITEM	CHECK OR MAINTENANCE JOB	Whichever comes first ⇒	INITIAL			EVERY		
				month	1	3	6	6	12
				km (mi)	320 (200)	1300 (800)	2500 (1600)	2500 (1600)	5000 (3200)
				hours	20	80	160	160	320
22	Engine oil filter cartridge	• Replace.		√			√	√	
23	Differential gear oil	• Change. • Check ATV for oil leakage, and correct if necessary.		√				√	
24	Final gear oil	• Change. • Check ATV for oil leakage, and correct if necessary.		√				√	
25	Cooling system	• Check coolant level and ATV for coolant leakage, and correct if necessary.		√	√	√	√	√	
		• Replace coolant.	Every 2 years						
26	* Moving parts and cables	• Lubricate.			√	√	√	√	
27	* Drive select lever safety system cable	• Check operation and adjust or replace if necessary.				√	√	√	
28	* Throttle lever housing and cable	• Check operation and correct if necessary. • Check throttle cable free play and adjust if necessary. • Lubricate throttle lever housing and cable.		√	√	√	√	√	
29	* Front and rear brake switches	• Check operation and correct if necessary.		√	√	√	√	√	
30	* Lights and switches	• Check operation and correct if necessary. • Adjust headlight beams.		√	√	√	√	√	


EBU23070

NOTE:

- The air filter needs more frequent service if you are riding in unusually wet or dusty areas.
- Hydraulic brake service
 - Regularly check and, if necessary, correct the brake fluid level.
 - Every two years replace the internal components of the brake master cylinders and calipers, and change the brake fluid.
 - Replace the brake hoses every four years and if cracked or damaged.


ENGINE SKID PLATES, SEAT, CARRIERS AND FENDERS

ENGINE SKID PLATES



Order	Job/Part	Q'ty	Remarks
	Removing the engine skid plates		
1	Front engine skid plate	1	Remove the parts in the order listed.
2	Center engine skid plate	1	
3	Rear engine skid plate	1	
			For installation, reverse the removal procedure.


SEAT AND SIDE PANELS




Order	Job/Part	Q'ty	Remarks
1	Removing the seat and side panels Seat	1	Remove the parts in the order listed. NOTE: _____ Pull up the seat lock lever, then pull up on the rear of the seat.
2	Battery cover	1	
3	Fuel tank cover	1	
4	Left side panel	1	
5	Right side panel	1	
6	Dipstick accessing panel	1	
			For installation, reverse the removal procedure.

EBS00037

FRONT CARRIER AND FRONT GUARD




Order	Job/Part	Q'ty	Remarks
	Removing the front carrier and front guard		Remove the parts in the order listed.
	Front engine skid plate		Refer to "ENGINE SKID PLATES".
	Seat/side panels		Refer to "SEAT AND SIDE PANELS".
1	Front carrier	1	
2	Front carrier bracket	2	
3	Battery holding bracket	1	
4	Battery lead	2	Disconnect.
			CAUTION: _____
			First disconnect the negative battery lead, then disconnect the positive lead.
5	Battery	1	
6	Upper panel	1	



Order	Job/Part	Q'ty	Remarks
7	Front guard	1	For installation, reverse the removal procedure.
8	Front guard cover	2	


FRONT FENDERS AND FRONT GRILL



Order	Job/Part	Q'ty	Remarks
	Removing the front fenders and front grill		Remove the parts in the order listed.
	Seat/side panels		Refer to "SEAT AND SIDE PANELS".
	Front carrier/front guard		Refer to "FRONT CARRIER AND FRONT GUARD".
1	Front fender inner panel	2	
2	Auxiliary DC jack coupler	1	Disconnect.
3	Main switch coupler	1	Disconnect.
4	Front fender	2	
5	Headlight coupler	2	Disconnect.
6	Front grill	1	
			For installation, reverse the removal procedure.

EBS00040


REAR CARRIER AND REAR FENDER




Order	Job/Part	Q'ty	Remarks
	Removing the rear carrier and rear fender		Remove the parts in the order listed.
	Seat/side panels		Refer to "SEAT AND SIDE PANELS".
1	Rear carrier	1	
2	Rear carrier bracket	2	
3	Storage compartment	1	
4	Tail/brake light cover	1	
5	Tail/brake light connector	3	Disconnect.
6	Rear fender	1	For installation, reverse the removal procedure.

ELECTRICAL COMPONENTS TRAY

ELECTRICAL COMPONENTS TRAY 1/2




Order	Job/Part	Q'ty	Remarks
	Removing the electrical components tray		Remove the parts in the order listed.
	Front fender/front grill		Refer to "FRONT FENDERS AND FRONT GRILL".
1	Battery holding bracket	1	
2	Battery lead	2	Disconnect. CAUTION: <u>First disconnect the negative battery lead, then disconnect the positive lead.</u>
3	Battery	1	
4	Lean angle sensor coupler	1	Disconnect.
5	Lean angle sensor	1	
6	EPS control unit coupler	5	Disconnect.




Order	Job/Part	Q'ty	Remarks
7	EPS (electric power steering) control unit	1	
8	Four-wheel-drive motor relay 3	1	
9	Rear brake relay	1	
10	Four-wheel-drive motor relay 2	1	
11	Four-wheel-drive motor relay 1	1	
12	Headlight relay	1	
13	Radiator fan motor coupler	1	Disconnect.
14	ECU coupler	1	Disconnect.
15	ECU (engine control unit)	1	
			For installation, reverse the removal procedure.

ELECTRICAL COMPONENTS TRAY 2/2




Order	Job/Part	Q'ty	Remarks
	Removing the electrical components tray		Remove the parts in the order listed.
1	Starter relay coupler	1	Disconnect.
2	Starter relay	1	
3	Fuse box	1	
4	EPS fuse	1	
5	Main fuse	1	
6	Spare fuse	1	
7	Radiator fan motor relay	1	
8	Fuel injection system relay	1	
9	Starting circuit cut-off relay	1	
10	Left handlebar switch coupler	2	Disconnect.
11	On-command four-wheel-drive motor switch and differential gear lock switch coupler	2	Disconnect.



Order	Job/Part	Q'ty	Remarks
12	Front brake light switch connector	2	Disconnect.
13	Rear brake light switch connector	2	Disconnect.
14	Meter assembly coupler	1	Disconnect.
15	Meter assembly	1	
16	Frame ground terminal	1	
17	Ignition coil connector	2	Disconnect.
18	Differential gear motor coupler	1	Disconnect.
19	Wire harness	1	
20	Electrical components tray	1	
			For installation, reverse the removal procedure.


EBS00045

FOOTREST BOARDS



Order	Job/Part	Q'ty	Remarks
	Removing the footrest boards		
	Seat/side panels		Remove the parts in the order listed. Refer to "SEAT AND SIDE PANELS".
1	Footrest	2	
2	Footrest board	2	
3	Footrest bracket	2	
			For installation, reverse the removal procedure.

AIR FILTER CASE



Order	Job/Part	Q'ty	Remarks
	Removing the air filter case		Remove the parts in the order listed. Refer to "SEAT AND SIDE PANELS".
	Seat/side panels		
1	Air filter case cover	1	
2	Air filter element	1	
3	Air filter element frame	1	
4	Air filter case joint clamp screw	1	Loosen.
5	Intake air temperature sensor coupler	1	Disconnect.
6	Breather hose (air filter case to throttle body)	1	Disconnect.
7	Breather hose (air filter case to fast idle plunger unit)	1	Disconnect.
8	Cylinder head breather hose	1	Disconnect.
9	Intake air temperature sensor	1	
10	Air filter case	1	
			For installation, reverse the removal procedure.

EAS00049

ENGINE

ADJUSTING THE VALVE CLEARANCE


The following procedure applies to all of the valves.

NOTE: _____

- Valve clearance adjustment should be made on a cold engine, at room temperature.
- When the valve clearance is to be measured or adjusted, the piston must be at top dead center (TDC) on the compression stroke.


1. Remove:

- left side panel
Refer to "SEAT AND SIDE PANELS".
- front fender
Refer to "FRONT FENDERS AND FRONT GRILL".
- footrest board
Refer to "FOOTREST BOARDS".
- air filter case
Refer to "AIR FILTER CASE".



2. Remove:


- fast idle plunger unit ①



3. Remove:

- intake tappet cover ①
- exhaust tappet cover
- camshaft sprocket cover ②


ADJUSTING THE VALVE CLEARANCE



- c. Measure the valve clearance with a thickness gauge ①.

	Thickness gauge 90890-03079 Narrow gauge set YM-34483
---	--


Out of specification → Adjust.




8. Adjust:
- valve clearance



- Loosen the locknut ①.
- Insert a thickness gauge ② between the end of the adjusting screw and the valve tip.
- Turn the adjusting screw ③ with the tappet adjusting tool ④ until the specified valve clearance is obtained.

	Tappet adjusting tool 90890-01311 Valve adjuster 3 mm & 4 mm YM-08035-A
---	--


- Hold the adjusting screw to prevent it from moving and tighten the locknut to the specified torque.

	Locknut 14 Nm (1.4 m · kg, 10 ft · lb)
---	---


- Measure the valve clearance again.
- If the valve clearance is still out of specification, repeat all of the valve clearance adjustment steps until the specified clearance is obtained.



9. Install:
- timing mark accessing screw


 **6 Nm (0.6 m · kg, 4.3 ft · lb)**

- crankshaft end accessing screw

 **10 Nm (1.0 m · kg, 7.2 ft · lb)**

10. Install:


- spark plug

 **13 Nm (1.3 m · kg, 9.4 ft · lb)**

11. Connect:


- spark plug cap

ADJUSTING THE VALVE CLEARANCE/ ADJUSTING THE ENGINE IDLING SPEED




12. Install:


- O-ring **New**
- camshaft sprocket cover

 10 Nm (1.0 m · kg, 7.2 ft · lb)

- O-ring ① **New**
- intake tappet cover

 10 Nm (1.0 m · kg, 7.2 ft · lb)

- O-ring **New**
- exhaust tappet cover

 10 Nm (1.0 m · kg, 7.2 ft · lb)

13. Install:

- fast idle plunger unit

14. Install:

- air filter case
Refer to “AIR FILTER CASE”.
- footrest board
Refer to “FOOTREST BOARDS”.
- front fender
Refer to “FRONT FENDERS AND FRONT GRILL”.
- left side panel
Refer to “SEAT AND SIDE PANELS”.

EBS00051

ADJUSTING THE ENGINE IDLING SPEED

1. Remove:

- fuel tank cover
Refer to “SEAT AND SIDE PANELS”.

2. Start the engine and let it warm up for several minutes.

3. Attach:

- tachometer
(to the spark plug lead)



Digital tachometer
90890-06760, YU-39951-B

4. Measure:

- engine idling speed
Out of specification → Adjust.



Engine idling speed
1,350 ~ 1,450 r/min